Originale	Sostituto
AVR/AVC On	Power
AVR/AVC Off	Shift + Power
Power Tv	TV/R
Power VCR	Smart
Power DVD/VDP	Media
PHONO	1
CD	2
DVD/VDP	3
VCR-1	4
VCR-2 / V.AUX	5
TV/DBS	6
MD/Tape Mon	7
Tuner	8
Shift	9
Video Select	0
Input Mode	Guide
Surround Mode	Pre Ch

Originale	Sostituto
<< Deck-VCR	Shift + <<
< Deck-VCR	Shift + Play
Deck-VCR >	Shift + Pause
Deck-VCR >>	Shift + >>
Stop Deck-VCR	Shift + Stop
CH+	Ch +
CH-	Ch -
Disc Skip+	Blue
Play CD/MD/CDR-DVD/	Play
Stop CD/MD/CDR-DVD/	Stop
Pause CD/MD/CDR-DVD/	Pause
CD/MD/CDR-DVD/ VDP >>I	>>I
I<< CD/MD/CDR-DVD/	I<<
CD/MD/CDR-DVD/ VDP >>	>>
<< CD/MD/CDR-DVD/	<<
System/Setup	Menu
Surround/Menu	D. Menu

Originale		Sostituto	
T.TONE RETURN	T.Tone/Return	RETURN BACK	Back
STATUS DISPLAY	Status/Display	DISPLAY INFO	Info
▲	Up	▲	Up
▼	Down	▼	Down
►	Right	►	Right
◄	Left	◄	Left
CH SELECT SELECT	CH.Select/Select	OK	Ok
▲ MASTER VOL	Master Volume	+ VOL	Vol +
MASTER VOL ▼	Master Volum	VOL –	Vol -
MUTING	Muting	MUTE	Mute
▲ VOLUME	Tv Vol+	SHIFT + + VOL	Shift + Vol +
▼ VOLU	Tv Vol-	SHIFT + VOL –	Shift + Vol -
+ ANNEL	Tv CH+	SHIFT + + CH	Shift + Ch +
– CHAN	Tv CH-	SHIFT + CH –	Shift + Ch -

Originale	Sostituto

Originale	Sostituto	Originale	Sostituto
AVR/AVC On	Power		
AVR/AVC Off	SHIFT + Shift + Power		
Play CD/MD/CDR-DVD/	PLAY MODE Play		
Pause CD/MD/CDR-DVD/	Pause		
Stop CD/MD/CDR-DVD/	Stop		
CD/MD/CDR-DVD/ VDP >>I	>>I		
I<< CD/MD/CDR-DVD/	I<<		
CD/MD/CDR-DVD/ VDP >>	>>		
<< CD/MD/CDR-DVD/	<<		

Originale	Sostituto
AVR/AVC On	Power
AVR/AVC Off	Shift + Power
CH+	Ch +
CH-	Ch -
Deck-VCR >>	>>
<< Deck-VCR	<<
Deck-VCR >	Shift + Pause
Stop Deck-VCR	Shift + Stop
Title CD/MD/CDR-DVD/	Exit
Disc Skip+ CD/MD/CDR-DVD/	Blue
Play CD/MD/CDR-DVD/	Play
Pause CD/MD/CDR-DVD/	Pause
Stop CD/MD/CDR-DVD/	Stop
CD/MD/CDR-DVD/ VDP >>I	>>I
I<< CD/MD/CDR-DVD/	I<<
System/Setup	Menu
Surround/Menu	D. Menu

Originale	Sostituto
T.Tone/Return	Back
Status/Display	Info
Up	Up
Down	Down
Right	Right
Left	Left
CH.Select/Select	Ok