Mandis shop

Sony RM-DX100

Originale		Sostituto	
DISC	Disc	A	Red
TRACK	Track	B	Green
GROUP	Group	C	Yellow
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10/0	10/0	0	0
ENTER	Enter	OK	Ok
CONTINUE	Continue		Right
SHUFFLE	Shuffle		Down
PROGRAM	Program		Left

Originale		Sostituto	
PROGRAM	Program	PROG SLEEP	Sleep
REPEAT	Repeat	REPEAT TEXT	Text
REPEAT	Repeat		Up
DISC –	Disc Skip -	CH –	Ch -
SKIP +	Disc Skip +	+ CH	Ch +
AMS I<<	I<< AMS	I<<	I<<
AMS >>I	AMS >>I	>>I	>>I
<<	<<	<<	<<
>>	>>	>>	>>
Stop	Stop	Stop	Stop
Play	Play	PLAY MODE	Play
Pause	Pause	Pause	Pause
MEMO	Memo	APP MEDIA	Media
	Line Out Level +	+ VOL	Vol +
LINE OUT LEVEL	Line Out Level -	VOL –	Vol -
JOG ON/OFF	Jog On/Off	HOME SMART	Smart
ENTER	Enter	FAV PRE-CH	Pre Ch