Mandis shop

RB-7150

Originale		Sostituto	
POWER	Power		Power
▶▶I	>>I	⏭	>>I
I◀◀	I<<	⏮	I<<
■	Stop	■	Stop
CD ▶/II	Play CD	PLAY MODE ▶	Play
CD ▶/II	Pause CD	II	Pause
BAND	Band	SEARCH TV/R	TV/R
PRESET	Preset	HOME SMART	Smart
TUNER	Tuner	APP MEDIA	Media
TUN ^	Tun Up	+ CH	Ch +
TUN v	Tun Down	CH −	Ch -
TAPE	Tape	A	Red
PHONO	Phono	B	Green
TV	TV	C	Yellow
VCR	VCR	D	Blue
VOL ^	Vol+	+ VOL	Vol +
VOL v	Vol-	VOL −	Vol -

Originale		Sostituto	
MUTE RESET	Mute/Reset	MUTE	Mute

https://tutti-i-telecomandi.it/it/Sanyo/1063470-93559-telecomando-di-sostituzione-per-Sanyo-RB-7150.html