Originale		Sostituto	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
SUBTITLE POSITION MEMORY	Subtitle	AD SUBT	Subt
SUBTITLE POSITION MEMORY	Position	SHIFT + APP MEDIA	Shift + Media
SETUP GROUP	Group	SHIFT + HOME SMART	Shift + Smart
SETUP GROUP	Setup	SETTINGS OPT	Options
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
≧10/-/--	>=10 / -/--	-/-- GUIDE	Guide

Originale		Sostituto	
DISC	Disc	FAV PRE-CH	Pre Ch
PRO LOGIC	DD Pro Logic	HOME SMART	Smart
CH SELECT TEST	CH Select	APP MEDIA	Media
CH SELECT TEST	Test	REPEAT TEXT	Text
SUPER SRND	Super SRND	CH –	Ch -
TOP MENU DIRECT NAVIGATOR	Top Menu / Direct Navigator	E-MANUAL D.MENU	D. Menu
TOP MENU DIRECT NAVIGATOR	Top Menu / Direct Navigator	DISC NAV LIST	List
TOP MENU DIRECT NAVIGATOR	EQ	SEARCH TV/R	TV/R
MENU PLAY LIST	Menu/Playlist	TOP MENU MENU	Menu
MENU PLAY LIST	Super Surround	PICTURE FORMAT	Format
S.3D AI EQ DISPLAY	Display	DISPLAY INFO	Info
S.3D AI EQ DISPLAY	Super 3D AI EQ	ECO 3D	3D
AV EFFECT RETURN	AV Effect	TIMER AV	AV
AV EFFECT RETURN	Return	RETURN BACK	Back
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok

Originale		Sostituto	
	Right		Right
	Down		Down
VCR(EXT)/ VDP(AUX)	VCR (Ext) / VDP (Aux)	A	Red
TAPE / DECK 1/2	TAPE / Deck 1/2	B	Green
DVD	DVD	C	Yellow
TUNER/ BAND	TUNER / BAND	D	Blue
CANCEL PLAY MODE	Play Mode	SHIFT + PLAY MODE	Shift + Play
CANCEL PLAY MODE	Cancel	CLEAR EXIT	Exit
	Rev. Play / Pause		Pause
	Stop		Stop
	Play	PLAY MODE	Play
	<< Slow/Search		<<
	Slow/Search >>		>>
	I<< Skip		I<<
	Skip >>I		>>I
MIX 2CH AUDIO	Audio	SOUND DUAL	Dual
MIX 2CH AUDIO	Mix 2CH	ZOOM	Eject

Originale		Sostituto	
DIGITAL S.WOOFER	Digital S.Woofer	+ CH	Ch +
MUTING	Muting	MUTE	Mute
VOLUME −	Volume-	VOL −	Vol -
VOLUME +	Volume+	+ VOL	Vol +