Originale		Sostituto	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DIMMER	Dimmer	DISC NAV LIST	List
A	Speakers A	A	Red
B	Speakers B	B	Green
COAXIAL	Coaxial	1	1
OPTICAL	Optical	2	2
NET	Net	3	3
LINE 1	Line 1	4	4
LINE 2	Line 2	5	5
LINE 3	Line 3	6	6
MODE	Mode	PICTURE FORMAT	Format
TUNER	Tuner	7	7
CD	CD	8	8
FM	FM	SEARCH TV/R	TV/R
TUNING	<< Tuning	<<	<<
TUNING	Tuning >>	>>	>>

Originale		Sostituto	
AM	AM	APP MEDIA	Media
PRESET	< Preset	CH –	Ch -
PRESET	Preset >	+ CH	Ch +
POP-UP MENU	Pop-Up Menu	TOP MENU MENU	Menu
HOME	Home	HOME SMART	Smart
NOW PLAYING	NDW Playing	D	Blue
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
SETUP	Setup	E-MANUAL D.MENU	D. Menu
RETURN	Return	RETURN BACK	Back
VOLUME	Volume+	+ VOL	Vol +
VOLUME	Volume-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
	Stop		Stop

Originale	Sostituto	Originale	Sostituto
Pause	Pause		
Play	Play		
I<<	I<<		
Option	Options		
>>I	>>I		
Display	Info		
Repeat	Text		
Shuffle	AV		