Originale		Sostituto	
	On / Standby		Power
	Input Selector V1		1
	Input Selector V2		2
	Input Selector V3		3
	Input Selector Multi CH		5
	Input Selector		6
	Input Selector		7
	Input Selector Tuner		8
	Input Selector CD		9
	Dimmer		0
	Sleep		Sleep / Timer
	Guide/Top		Menu / Home
	Muting		Mute / Dimmer
	Return		Back / Return
	Setup		Eject / Surround
	Enter		OK
	Up		Up

Originale		Sostituto	
	Down		Down
	Right		Right
	Left		Left
	Play		Play / Slow
	Rev. Play		Pause / Step / Freeze
	Stop		Stop / Hold
	<<		>> / Tune+
	>>		I<< / Preset-
	I<<		<< / Tune-
	>>I		>>I / Preset+
	Listening Mode Stereo		Red / Netflix / Search
	Listening Mode Surround		Green / APP / Repeat
	Listening Mode <		Yellow / YouTube / Repeat
	Listening Mode >		Blue / Prime Video / Random
	Test Tone/Audio		Audio / Lang I/II
	CH Sel/Subtitle		Subtitle / EQ
	Level-/Random		TV/Radio / Program

Originale	Sostituto
REPEAT LEVEL+ Level+/Repeat	SIZE ZOOM Zoom / Size
DISPLAY Display	ANGLE INFO Info / Angle
L NIGHT DVD L.Night	LIST SMART Smart / List
CINE FLTR HDD Cine FLTR	MEDIA DISPLAY Display / Media
INPUT Input Tv	SHIFT + RDS AV INPUT Shift + AV / Input / RDS
CH DISC ALBUM + CH/Disc/Album	+ CH PAGE CH+ / Page+
CH DISC ALBUM − CH/Disc/Album-	CH PAGE − CH- / Page-
VOL ▲ Vol+	+ VOL Vol+
VOL ▼ Vol-	VOL − Vol-
I/⏻ Power Tv/Standby	SHIFT + ⏻ Shift + Power
VOL ▲ Vol+ Tv	SHIFT + + VOL Shift + Vol+
VOL ▼ Vol- Tv	SHIFT + VOL − Shift + Vol-
1 V1 1 Tv	SHIFT + TV 1 Shift + 1
2 V2 2 Tv	SHIFT + DVD 2 Shift + 2
3 V3 3 Tv	SHIFT + CD - STB 3 Shift + 3
4 V4 4 Tv	SHIFT + VIDEO 4 Shift + 4
5 MULTI CH 5 Tv	SHIFT + TAPE 5 Shift + 5

Originale	Sostituto
6 DVD 6 Tv	SHIFT + TUNER 6 Shift + 6
7 TAPE 7 Tv	SHIFT + AUX - HDD 7 Shift + 7
8 TUNER 8 Tv	SHIFT + USB 8 Shift + 8
9 CD 9 Tv	SHIFT + BLUETOOTH 9 Shift + 9
0 DIMMER 0 Tv	SHIFT + HDMI - SAT 0 Shift + 0
+10 D TUN -/-- +10 Tv	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--
PREVIOUS MENU MUTING Muting/Previous Menu Tv	SHIFT + DIMMER MUTE Shift + Mute / Dimmer
ENTER Enter Tv	SHIFT + OK Shift + OK
PLAYLIST/CAT► Right Tv	SHIFT + ► Shift + Right
◄PLAYLIST/CAT Left Tv	SHIFT + ◄ Shift + Left
SETUP Setup Tv	TOP MENU D.MENU D.Menu / Top
▲ Up Tv	SHIFT + ▲ Shift + Up
▼ Down Tv	SHIFT + ▼ Shift + Down

Originale		Sostituto	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
+10	+10/10/-/--	GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI - SAT 0	0
CLR	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home

Originale		Sostituto	
PREVIOUS MENU MUTING	Previous Menu/Muting	DIMMER MUTE	Mute / Dimmer
PLAYLIST/CAT-	Left/Playlist/Cat-		Left
ENTER	Enter	OK	OK
PLAYLIST/CAT+	Right/Playlist/Cat		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-

Originale	Sostituto	Originale	Sostituto
Listening Mode >	SHIFT + PRESET+ (>>I)		
AUDIO / TEST TONE	LANG I/II / AUDIO		
SUBTITLE / CH SEL	EQ / SUBTITLE		
RANDOM / LEVEL-	Prime Video / RANDOM		
REPEAT / LEVEL+	APP / REPEAT		
DISPLAY	MEDIA / DISPLAY		
PLAY MODE / VCR	FORMAT / PICTURE		
L NIGHT / DVD	SHIFT + DVD 2		
CINE FLTR / HDD	SHIFT + AUX - HDD 7		

Shift + >>I / Preset+

Audio / Lang I/II

Subtitle / EQ

Blue / Prime Video / Random

Green / APP / Repeat

Display / Media

Picture / Format

Shift + 2

Shift + 7

Originale		Sostituto	
ON/STANDBY	On / Standby		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI-SAT 0	0
CLR	12	PC FAV MARKER	Fav / Marker / PC
CH	Disc+	CH PAGE +	CH+ / Page+
VOL	Vol+	VOL +	Vol+
CH	Disc-	CH PAGE −	CH- / Page-
VOL	Vol-	VOL −	Vol-

Originale		Sostituto	
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
RANDOM LEVEL-	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Originale		Sostituto	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI-SAT 0	0
CH DISC ALBUM +	CH+	CH PAGE +	CH+ / Page+
CH DISC ALBUM −	CH-	CH PAGE −	CH- / Page-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Originale		Sostituto	
	<<	TUNE-	<< / Tune-
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
PLAY MODE VCR	Play Mode	TOP MENU D.MENU	D.Menu / Top
L NIGHT DVD	L.Night	TIMER SLEEP	Sleep / Timer