Originale		Sostituto	
POWER	Power		Power
MARKER	Marker	HOME SMART	Smart
OPEN/CLOSE	Open/Close	ZOOM	Eject
SEARCH	Search	SEARCH TV/R	TV/R
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	A	Red
RANDOM	Random	APP MEDIA	Media
PROGRAM	Program	PROG SLEEP	Sleep
CLEAR	Clear	CLEAR EXIT	Exit
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Originale		Sostituto	
8	8	8	8
9	9	9	9
0	0	0	0
SKIP	I<<		I<<
PLAY	Play	PLAY MODE	Play
SKIP	>>I		>>I
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
STOP	Stop		Stop
PAUSE/STEP	Pause/Step		Pause
DISPLAY	Display	DISPLAY INFO	Info
SLOW	<I Slow		<<
SLOW	Slow I>		>>
SELECT/ENTER	Select/Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Originale	Sostituto	Originale	Sostituto
MENU Menu	TOP MENU MENU Menu		
TITLE Title	DISC NAV LIST List		
SETUP Setup	SETTINGS OPT Options		
RETURN Return	RETURN BACK Back		
REPEAT Repeat	REPEAT TEXT Text		
A-B A-B	PICTURE FORMAT Format		