Mandis shop

CUCLD072

Originale		Sostituto	
POWER	Power		Power
16:9	16:9	FORMAT PICTURE	Picture / Format
EJECT	Stop/Eject	HOLD	Stop / Hold
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SKIP	I<< Skip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
SCAN	<< Scan	TUNE-	<< / Tune-
SCAN	Scan >>	TUNE+	>> / Tune+
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
HILITE /INTRO	Hilite/Intro	OK	OK
D-LEVEL CTRL	D-Level CTRL	LIST SMART	Smart / List
+	+	VOL +	Vol+
-	-	VOL -	Vol-
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Originale		Sostituto	
A REPEAT	Repeat A	NETFLIX SEARCH	Red / Netflix / Search
REPEAT B	Repeat B	APP REPEAT	Green / APP / Repeat

https://tutti-i-telecomandi.it/it/Pioneer/1065581-83267-telecomando-di-sostituzione-per-Pioneer-CU-CLD072.html