Originale		Sostituto	
POWER	Power	POWER	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TEXT ▶II	Play	SLOW ▶	Play / Slow
TEXT ▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze
HOLD ■	Stop	HOLD ■	Stop / Hold
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
INDEX I◀◀	I<<	PRESET- I◀◀	I<< / Preset-
SIZE ▶▶I	>>I	PRESET+ ▶▶I	>>I / Preset+
SMODE	S.Mode	TITLE SOUND	Sound / Title
REVEAL AUDIO	Audio/Reveal	LANG I/II AUDIO	Audio / Lang I/II
SUBPAGE ZOOM	Zoom/Subpage	EQ SUBTITLE	Subtitle / EQ
PMODE	P.Mode	FORMAT PICTURE	Picture / Format
SIZE ▶▶I	Size	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MENU	D.Menu	TOP MENU D.MENU	D.Menu / Top
TEXT ▶II	Text	GOTO TEXT	Text / Goto

Originale		Sostituto	
INPUT	Input	RDS AV INPUT	AV / Input / RDS
LCD MENU	LCD Menu	HOME MENU	Menu / Home
▲	Up	▲	Up
INDEX I◀◀	Index	ANGLE INFO	Info / Angle
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
⟲	Recall	RETURN BACK	Back / Return
+ VOL	Vol+	+ VOL	Vol+
DVD SETUP	DVD Setup	LIST SMART	Smart / List
+ CH.	CH+	+ CH PAGE	CH+ / Page+
VOL	Vol-	VOL –	Vol-
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CH. –	CH-	CH PAGE –	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2

Originale		Sostituto	
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
AUTO	Auto	PC FAV MARKER	Fav / Marker / PC
PROGRAM	Red/Program	NETFLIX SEARCH	Red / Netflix / Search
INTRO	Green/Intro	APP REPEAT	Green / APP / Repeat
REPEAT	Yellow/Repeat	YouTube REPEAT A-B	Yellow / YouTube / Repeat
A-B	Blue/A-B	Prime Video RANDOM	Blue / Prime Video / Random
HOLD	Hold	SHIFT + HOLD	Shift + Stop /
TITLE	Title	SHIFT + TITLE SOUND	Shift + Sound / Title
NICAM	Nicam	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II

Originale		Sostituto	
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
D.SUB	D.Subt.	SHIFT + SIZE ZOOM	Shift + Zoom /
GOT	Goto	SHIFT + GOTO TEXT	Shift + Text /
ANGLE	Angle	SHIFT + ANGLE INFO	Shift + Info / Angle
PGUP SLOW	Slow/PgUp	SHIFT + CH PAGE +	Shift + CH+ /
D.DISP	D.Disp	SHIFT + MEDIA DISPLAY	Shift + Display / Media
PGDW STE	Step/PgDn	SHIFT + CH PAGE −	Shift + CH- /