Mandis shop

CABASSE

| Originale | | Sostituto | | Originale | Sostituto |
|---|---|---|---|---|---|
| | Power | | Power | | |
| | Mute | DIMMER MUTE | Mute / Dimmer | | |
| | [)(] | SURROUND | Eject / Surround | | |
| HDMI IN | HDMI In | HDMI - SAT 0 | 0 | | |
| | + | + VOL | Vol+ | | |
| | [+] | FORMAT PICTURE | Picture / Format | | |
| TV ARC | Tv ARC | TV 1 | 1 | | |
| | - | VOL − | Vol- | | |
| | Sleep | TIMER SLEEP | Sleep / Timer | | |
| S/PDIF | S/PDIF | OPT-TOOLS SETUP | Setup / OPT / | | |
| BASS | Bass | LANG I/II AUDIO | Audio / Lang I/II | | |
| | ♫ | TITLE SOUND | Sound / Title | | |
| | Bluetooth | BLUETOOTH 9 | 9 | | |
| | Receptor | USB 8 | 8 | | |
| STD | STD | EQ SUBTITLE | Subtitle / EQ | | |
| | | | | | |
| | | | | | |

https://tutti-i-telecomandi.it/it/ORANGE/1066294-94130-telecomando-di-sostituzione-per-ORANGE-CABASSE.html