Mandis shop

WOX002

Originale		Sostituto	
	Power		Power
	Mute		Mute / Dimmer
	Shuffle		Blue / Prime Video / Random
	[/]		>>I / Preset+
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Up		Up
	Down		Down
	Left		Left

Originale		Sostituto	
	Right		Right
OK	OK	OK	OK
ESC	Esc		Exit / Cancel / Clear
SNAP SHOT	Snap Shot		Smart / List
CH	CH+		CH+ / Page+
CH	CH-		CH- / Page-
VOL	Vol+		Vol+
VOL	Vol-		Vol-
	Pause/Step		Pause / Step / Freeze
RECORD	Record		Rec / Rec Mode
STOP	Stop		Stop / Hold

https://tutti-i-telecomandi.it/it/Woxter/1066601-82064-telecomando-di-sostituzione-per-Woxter-WOX002.html