Mandis shop

REMCON2008

Originale		Sostituto		Originale		Sostituto	
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /				
-10	-10	-/-- GUIDE EPG	Guide / EPG / -/--				
+10	+10	PC FAV MARKER	Fav / Marker / PC				
▶/II	Play	SLOW ▶	Play / Slow				
▶/II	Pause	STEP - FREEZE II	Pause / Step / Freeze				
I◀◀/◀◀	<<	TUNE- ◀◀	<< / Tune-				
I◀◀/◀◀	I<<	PRESET- I◀◀	I<< / Preset-				
▶▶/▶▶I	>>	TUNE+ ▶▶	>> / Tune+				
▶▶/▶▶I	>>I	PRESET+ ▶▶I	>>I / Preset+				
STOP	Stop	HOLD ■	Stop / Hold				
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat				
VOL-	Vol-	VOL −	Vol-				
VOL+	Vol+	+ VOL	Vol+				

https://tutti-i-telecomandi.it/it/PRO-BASIC/1066622-96443-telecomando-di-sostituzione-per-PRO-BASIC-REMCON2008.html