Mandis shop

WL-61

Originale		Sostituto		Originale		Sostituto	
START /STOP	Start/Stop		Power				
W	Zoom W	CH PAGE +	CH+ / Page+				
T	Zoom T	CH PAGE −	CH- / Page-				
	Left		Left				
	Up		Up				
	Right		Right				
	Down		Down				
PLAY	Play	SLOW ▶	Play / Slow				
STOP	Stop	HOLD ■	Stop / Hold				
EXECUTE	Execute	OK	OK				
REW/	<</Rew	TUNE- ◀◀	<< / Tune-				
FF/	>>/FF	TUNE+ ▶▶	>> / Tune+				
COUNTER RESET	Counter Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
PAUSE	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze				
ON SCREEN	On Screen	MEDIA DISPLAY	Display / Media				
TAPE RETURN	Tape Return	RETURN BACK	Back / Return				

https://tutti-i-telecomandi.it/it/Canon/1067054-79814-telecomando-di-sostituzione-per-Canon-WL-61.html