Mandis shop

REMCON2136

Originale		Sostituto		Originale	Sostituto
TUNER	Tuner	TUNER 6	6		
CD	CD	CD - STB 3	3		
DOWN I<<	I<</Down	PRESET- I<<	I<< / Preset-		
UP >>I	>>I/Up	PRESET+ >>I	>>I / Preset+		
▶II	Play	SLOW ▶	Play / Slow		
▶II	Pause	STEP - FREEZE II	Pause / Step / Freeze		
M-UP REPEAT	M-Up/Repeat	APP REPEAT	Green / APP / Repeat		
MEMORY CLOCK	Memory/Clock	TIMER SLEEP	Sleep / Timer		
STOP	Stop	HOLD ■	Stop / Hold		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
BAND	Band	PROGRAM TV/RADIO	TV/Radio /		
POWER	Power	⏻	Power		
– VOLU	Volume-	VOL –	Vol-		
LUME +	Volume+	+ VOL	Vol+		

https://tutti-i-telecomandi.it/it/Roadstar/1067276-96946-telecomando-di-sostituzione-per-Roadstar-REMCON2136.html