Originale		Sostituto	
STANDBY	Power	STANDBY	Power
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
INTRO PREVIEW	Preview/Intro	RETURN BACK	Back / Return
Dolby	Dolby	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TITLE/PBC ALT	ALT/Title/PBC	TITLE SOUND	Sound / Title
0/10	0/10	HDMI - SAT 0	0

Originale		Sostituto	
10+	10+	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
SETUP MENU	Menu/Setup	HOME MENU	Menu / Home
RETURN EXIT	Exit/Return	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SUBTITLE SUB	Sub./Subtitle	EQ SUBTITLE	Subtitle / EQ
⬆/CH-	Up	▲	Up
⬆/CH-	CH+	+ CH PAGE	CH+ / Page+
➡	Right	▶	Right
⬅	Left	◀	Left
▶/ENTER	Enter	OK	OK
▶/ENTER	Play	SLOW ▶	Play / Slow
⬇/CH-	CH-	CH PAGE −	CH- / Page-
⬇/CH-	Down	▼	Down
MENU TEXT	Blue/Text/Menu	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO AUD	Green/Audio	APP REPEAT	Green / APP / Repeat
PAUSE ⏸	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
PAUSE ⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
LANGUAGE LANG	Red/Language	NETFLIX SEARCH	Red / Netflix / Search

Originale	Sostituto
List/Angle	Smart / List
Info/Display	Info / Angle
DVD/DVB/Functio	Display / Media
Vol+	Vol+
Tv/Radio	TV/Radio /
Game	Picture / Format
Vol-	Vol-
Favor.	Fav / Marker / PC
Auto Scan	AV / Input / RDS
Stop	Stop / Hold
Slow	Shift + Play /
EPG/Program	Guide / EPG / -/--
I<<	I<< / Preset-
>>I	>>I / Preset+
Clear	Shift + Exit / Cancel / Clear
<<	<< / Tune-
>>	>> / Tune+

Originale	Sostituto
Memory	D.Menu / Top
Repeat	Shift + Green / APP /
A-B	Shift + Yellow / YouTube /
A-Time	Setup / OPT /