Originale		Sostituto	
VTR	VTR		Power
SCANNER ON/OFF	Scanner On/Off	OPT-TOOLS SETUP	Setup / OPT /
TRANSMIT	Transmit	LIST SMART	Smart / List
PAUSE/STILL	Pause/Still	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
STILL ADV	Still Adv	Prime Video RANDOM	Blue / Prime Video / Random
REW/⊖	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
⊕/FF	>>	TUNE+	>> / Tune+
REC	Rec	REC MODE	Rec / Rec Mode
-	-		Left
SEARCH	Search	OK	OK
CH	+		Right
CLOCK/ COUNTER	Clock/Counter	PC FAV MARKER	Fav / Marker / PC
TAPE REMAIN	Tape Remain	MEDIA DISPLAY	Display / Media
RESET	Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MONITOR	Monitor	TOP MENU D.MENU	D.Menu / Top Menu

Originale		Sostituto	
AV LINK	AV Link	PROGRAM TV/ RADIO	TV/Radio /
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
INDE	I<< Index	PRESET-	I<< / Preset-
NDEX	Index >>I	PRESET+	>>I / Preset+
TRACKING	Tracking/V-Lock-	CH PAGE	CH- / Page-
NG/V-LOCK	Tracking/V-Lock+	CH PAGE	CH+ / Page+
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
ZERO STOP	Zero Stop	GOTO TEXT	Text / Goto
TIME SEARCH	Time Search	NETFLIX SEARCH	Red / Netflix / Search
AUDIO OUT	Audio Out	LANG I/II AUDIO	Audio / Lang I/II
SU 1	1	TV 1	1
MO 2	2	DVD 2	2
TU 3	3	CD - STB 3	3
WE 4	4	VIDEO 4	4
TH 5	5	TAPE 5	5
FR 6	6	TUNER 6	6
RECORDING UP SP	Recording SP/LP	FORMAT PICTURE	Picture / Format

Originale		Sostituto	
SA 7	7	AUX - HDD 7	7
SU~SA 8	8	USB 8	8
MO~SA 9	9	BLUETOOTH 9	9
MO~FR 0	0	HDMI - SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
TIMER REC	Timer Rec	TIMER SLEEP	Sleep / Timer
PAL/MESECAM	Pal/Mesecam	SIZE ZOOM	Zoom / Size

Originale	Sostituto

Originale	Sostituto	Originale	Sostituto
VTR	Power	Index >>I	>>I / Preset+
Scanner On/Off	TV/Radio /	Tracking/V-Lock-	CH- / Page-
Transmit	Setup / OPT /	Tracking/V-Lock+	CH+ / Page+
Pause/Still	Pause / Step / Freeze	Repeat	Green / APP / Repeat
Stop	Stop / Hold	Zero Stop	Exit / Cancel / Clear
Still Adv	Yellow / YouTube / Repeat	Audio Out	Mute / Dimmer
<<	<< / Tune-	1	1
Play	Play / Slow	2	2
>>	>> / Tune+	3	3
Rec	Rec / Rec Mode	4	4
-	Left	5	5
Search	Red / Netflix / Search	6	6
+	Right	Recording LP/SP	Picture / Format
Reset	Back / Return	7	7
AV Link	AV / Input / RDS	8	8
Input Select	Smart / List	9	9
I<< Index	I<< / Preset-	0	0

Originale	Sostituto	Originale	Sostituto
-/--	Guide / EPG / -/--		
Timer Rec	Text / Goto		