Mandis shop

RM-SEP30

Originale	Sostituto	Originale	Sostituto
Power	Power	I <<| <<	I << / Preset-
Volume+	Vol +	>>| >>I	>>I / Preset+
Music Menu	Menu / Home	Clock/Timer/Sleep Set	Sleep / Timer
Mega Bass	Sound / Title	Timer On/Off	Fav / Marker / PC
Volume-	Vol -	Repeat	Green / APP / Repeat
Tape	5		
CD/Remain	3		
Tuner/Band	6		
Preset +	Shift + >>I / Preset+		
Tuning/Clock/Timer +	>> / Tune+		
Tuner	OK		
Preset -	Shift + I << / Preset-		
Tuning/Clock/Timer -	<< / Tune-		
Shuffle	Smart / List		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

https://tutti-i-telecomandi.it/Sony/10622-550-telecomando-sostituzione-per-Sony-RM-SEP30-146271.htm