Originale		Sostituto	
STANDBY/ON	Standby/On		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10	10	0	0
+10	+10	GUIDE	Guide
+100	+100	PRE-CH	Pre Ch
+	Vol+	VOL +	Vol +
–	Vol-	VOL –	Vol -
MUTING	Mute	MUTE	Mute
MENU	Menu	TOP MENU MENU	Menu

Originale		Sostituto	
UP	Up		Up
DOWN	Down		Down
SET	Set	OK	Ok
SERVICE-	I<</<<Service		Left
SERVICE+	>>/>>I/Service		Right
CANCEL	Cancel	SHIFT + RETURN BACK	Shift + Back
CLOCK/TIMER	Clock/Timer	TIMER AV	AV
DISPLAY	Display	DISPLAY INFO	Info
SLEEP	Sleep	PROG SLEEP	Sleep
A.P.S.	A.P.S.	APP MEDIA	Media
PTY SEARCH	Stop/PTY		Stop
SOUND MODE	Sound Mode	SOUND DUAL	Dual
REPEAT	Repeat	REPEAT TEXT	Text
REC SPEED	Rec Speed	REC MODE	Rec
REC/DELETE	Rec Delete	RETURN BACK	Back
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec
FM MODE	FM Mode	SEARCH TV/R	TV/R

Originale	Sostituto	Originale	Sostituto
PLAY MODE Play Mode	PICTURE FORMAT Format		
TUNER Tuner	AD SUBT Subt		
SUPER WOOFER VOLUME Super Woofer	+ CH Ch +		
VOLUME Super Woofer Vol-	CH – Ch -		
DISTORTION LEVEL Distorsion Level +	>> >>		
LEVEL Distorsion Level -	<< <<		
USB Play/Pause USB	A Red		
CD Play/Pause CD	PLAY MODE ▶ Play		
iPod Play/Pause iPod	II Pause		
METRONOME Play/Pause Metronome	B Green		
Bluetooth Play/Pause Bluetooth	C Yellow		
AUDIO IN Audio In	D Blue		