Mandis shop

RMSUXVJ3WJ

Originale		Sostituto	
⏻/I	Power	⏻	Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
iPad ►/II	Play/Pause iPad	SLOW ►	Play / Slow
iPod ►/II	Play/Pause iPod	STEP-FREEZE II	Pause / Step / Freeze
TUNER	Tuner	TUNER 6	6
PC	PC	PC FAV MARKER	Fav / Marker / PC
AUDIO IN	Audio In	LANG I/II AUDIO	Audio / Lang I/II
MENU	Menu	HOME MENU	Menu / Home
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
UP	Up	▲	Up
DOWN	Down	▼	Down
I<<	I<<	PRESET- I<<	I<< / Preset-
>>I	>>I	PRESET+ >>I	>>I / Preset+
SET	Set	OK	OK
■	Stop	HOLD ■	Stop / Hold
<<	<<	TUNE- <<	<< / Tune-
>>	>>	TUNE+ >>	>> / Tune+

Originale		Sostituto	
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
TUNER MODE REPEAT	Repeat/Tuner	GOTO TEXT	Text / Goto
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
APS	APS	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
VOLUME +	Vol+	VOL +	Vol+
VOLUME −	Vol-	VOL −	Vol-
SOUND TURBO	Sound Turbo	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
HBS	HBS	TOP MENU D.MENU	D.Menu / Top
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND ⏏	Eject / Surround
RESUME	Resume	FORMAT PICTURE	Picture / Format
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer

https://tutti-i-telecomandi.it/it/JVC/1065501-79564-telecomando-di-sostituzione-per-JVC-RM-SUXVJ3-WJ.html