Originale	Sostituto	Originale	Sostituto
Power	Power	Enter	Ok
Display	Info	Right	Right
DVD / BD	Shift + 1	Down	Down
VCR / DVR	Shift + 2	Setup	Options
CBL/SAT	Shift + 3	Return	Back
CD	Shift + 4	Audio	Dual
AUX	Shift + 5	I <<	I <<
TV / TAPE	Shift + 6	>>I	>>I
TUNER	Shift + 7	<<	<<
PORT	Shift + 8	Play	Play
Muting	Mute	>>	>>
CH/Disc/Album	Ch +	Pause	Pause
CH/Disc/Album	Ch -	Stop	Stop
Vol +	Vol +	Movie	Red
Vol -	Vol -	Music/Repeat	Green
Up	Up	Game/Random	Yellow
Left	Left	Stereo/Play Mode	Blue

Originale		Sostituto		Originale		Sostituto	
1	1	1	1				
2	2	2	2				
3	3	3	3				
4	4	4	4				
5	5	5	5				
6	6	6	6				
7	7	7	7				
8	8	8	8				
9	9	9	9				
11 0	0/ 11	0	0				
10 +10 D.TUN DIMMER	+10/ - - / - - - 10/ Di mer / D. Tun	-/-- GUIDE	Gui de				
12 CLR SLEEP	CLR/ Sl eep/ 12	FAV PRE-CH	Pre Ch				

Originale		Sostituto
	Power BD/DVD	Power
	Menu/Prev CH	Menu
	Top Menu/Guide BD/DVD	Options
	Setup BD/DVD	Smart
	Return BD/DVD	Back
	Audio BD/DVD	Media
	Enter BD/DVD	Ok
	Up BD/DVD	Up
	Down BD/DVD	Down
	Right BD/DVD	Right
	Left BD/DVD	Left
	I<< BD/DVD	I<<
	>>I BD/DVD	>>I
	<< BD/DVD	<<
	>> BD/DVD	>>
	Play BD/DVD	Play
	Pause/Play rev. BD/DVD	Pause

Originale		Sostituto
	Stop BD/DVD	Stop
	Movie Tv/Search BD/DVD	Red
	Music/Repeat	Green
	Game/Random	Yellow
	Stereo/Play Mode BD/DVD	Blue
	1 BD/DVD	1
	2 BD/DVD	2
	3 BD/DVD	3
	4 BD/DVD	4
	5 BD/DVD	5
	6 BD/DVD	6
	7 BD/DVD	7
	8 BD/DVD	8
	9 BD/DVD	9
	0/11 BD/DVD	0
	+10/--/--10/D.Tuning Dimmer BD/DVD	Guide
	CLR/Sleep/12	Pre Ch

BD/DVD

Originale	Sostituto
CBL/SAT	Text
Muting Receiver	Mute
Vol + Receiver	Vol +
Vol - Receiver	Vol -
Power CBL/SAT	Shift + Power
CH Disc/Album+ CBL/SAT	Ch +
CH Disc/Album- CBL/SAT	Ch -
Menu/Prev CH CBL/SAT	Shift + Menu
Top Menu/Guide CBL/SAT	Shift + Options
Return CBL/SAT	Shift + Back
Setup CBL/SAT	Shift + Smart
Up CBL/SAT	Shift + Up
Enter CBL/SAT	Shift + Ok
Down CBL/SAT	Shift + Down
Right CBL/SAT	Shift + Right
Left CBL/SAT	Shift + Left
Pause/Play rev. CBL/SAT	Shift + Pause

Originale	Sostituto
Stop CBL/SAT	Shift + Stop
<< CBL/SAT	Shift + Ch -
>> CBL/SAT	Shift + Ch +
Play CBL/SAT	3D
Movie Tv/Search CBL/SAT	Dual
Music/Repeat CBL/SAT	Subt
Game/Random	AV
Stereo/Play Mode CBL/SAT	Format
1 CBL/SAT	Shift + 1
2 CBL/SAT	Shift + 2
3 CBL/SAT	Shift + 3
4 CBL/SAT	Shift + 4
5 CBL/SAT	Shift + 5
6 CBL/SAT	Shift + 6
7 CBL/SAT	Shift + 7
8 CBL/SAT	Shift + 8
9 CBL/SAT	Shift + 9

Originale	Sostituto	Originale	Sostituto
0/ 11 CBL/ SAT	SHIFT + 0 Shift + 0		
DVD/ BD	SEARCH TV/R TV/ R		

Originale		Sostituto	
	Power CD		Power
	CH/Disc+ CD		Ch +
	CH/Disc- CD		Ch -
	Return CD		Back
	Setup CD		Smart
	Audio CD		Media
	Up CD		Up
	Down CD		Down
	Right CD		Right
	Left CD		Left
	Enter CD		Ok
	I<< CD		I<<
	>>I CD		>>I
	<< CD		<<
	>> CD		>>
	Play CD		Play
	Pause CD		Pause

Originale		Sostituto	
	Stop CD		Stop
	Movie Tv/Search		Red
	Music/Repeat		Green
	Game/Random		Yellow
	Stereo/Play Mode		Blue
1	1 CD	1	1
2	2 CD	2	2
3	3 CD	3	3
4	4 CD	4	4
5	5 CD	5	5
6	6 CD	6	6
7	7 CD	7	7
8	8 CD	8	8
9	9 CD	9	9
0	0/11 CD	0	0
+10	+10/--/--10/D.Tu Dimmer CD	GUIDE	Guide
CLR SLEEP	CLR/Sleep/12	PRE-CH	Pre Ch

Originale	Sostituto	Originale	Sostituto
MUTING Muting Receiver	MUTE Mute		
VOL Vol + Receiver	+ VOL Vol +		
VOL Vol - Receiver	VOL − Vol -		
CD CD	SEARCH TV/R TV/R		

Originale		Sostituto	
ON/STANDBY	Power Receiver Zone 2		Power
MUTING	Muting Receiver	MUTE	Mute
VOL	Vol + Zone 2	VOL +	Vol +
VOL	Vol - Zone 2	VOL −	Vol -
CH DISC	CH Disc/Album+ Zone 2	CH +	Ch +
ALBUM	CH Disc/Album- Zone 2	CH −	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
PLAYLIST /CATEGORY	Right Zone 2		Right
PLAYLIST /CATEGORY	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
SETUP	Setup Zone 2	HOME SMART	Smart
AUDIO	Audio Zone 2	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
	Play Zone 2	PLAY MODE	Play

Originale		Sostituto	
	>> Zone 2		>>
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
MOVIE/TV SEARCH	Movie Tv/Search Zone 2	A	Red
LISTENI MUSIC REPEAT	Music/Repeat	B	Green
G MODE GAME RANDOM	Game/Random	C	Yellow
STEREO PLAY MODE	Stereo/Play Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9

Originale	Sostituto	Originale	Sostituto
0/ 11 Zone 2	0		
+10/ - - / - - 10/ D. Tu Dimmer Zone 2	Guide		
CLR/ Sleep/ 12	Pre Ch		