Originale		Sostituto	
ON/STANDBY	On / Standby		Power
1 V1	Input Selector V	TV 1	1
2 V2	Input Selector V	DVD 2	2
3 V3	Input Selector V	CD-STB 3	3
5 MULTI CH	Input Selector Multi CH	TAPE 5	5
6 DVD	Input Selector	TUNER 6	6
7 TAPE	Input Selector	AUX-HDD 7	7
8 TUNER	Input Selector Tuner	USB 8	8
9 CD	Input Selector C	BLUETOOTH 9	9
0 DIMMER	Dimmer	HDMI-SAT 0	0
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
GUIDE TOP MENU	Guide/Top	HOME MENU	Menu / Home
PREVIOUS MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
RETURN	Return	RETURN BACK	Back / Return
SETUP	Setup	SURROUND	Eject / Surround
ENTER	Enter	OK	OK
	Up		Up

Originale		Sostituto	
	Down		Down
PLAYLIST/CAT	Right		Right
PLAYLIST/CAT	Left		Left
	Play	SLOW	Play / Slow
	Rev. Play	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	<<	TUNE+	>> / Tune+
	>>	PRESET-	I<< / Preset-
	I<<	TUNE-	<< / Tune-
	>>I	PRESET+	>>I / Preset+
STEREO	Listening Mode Stereo	NETFLIX SEARCH	Red / Netflix / Search
SURROUND	Listening Mode Surround	APP REPEAT	Green / APP / Repeat
	Listening Mode <	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Listening Mode >	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO TEST TONE	Test Tone/Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE CH SEL	CH Sel/Subtitl	EQ SUBTITLE	Subtitle / EQ
RANDOM LEVEL-	Level -/Random	PROGRAM TV/RADIO	TV/Radio / Program

Originale	Sostituto
REPEAT LEVEL+ Level +/ Repeat	SIZE ZOOM Zoom / Size
DISPLAY Display	ANGLE INFO Info / Angle
L NIGHT DVD L. Night	LIST SMART Smart / List
CINE FLTR HDD Cine FLTR	MEDIA DISPLAY Display / Media
INPUT Input Tv	SHIFT + RDS AV INPUT Shift + AV / Input / RDS
CH DISC ALBUM + CH/Disc/Album	+ CH PAGE CH+ / Page+
CH DISC ALBUM − CH/Disc/Album-	CH PAGE − CH- / Page-
VOL + Vol +	+ VOL Vol +
VOL − Vol -	VOL − Vol -
Power Tv/Standby	SHIFT + Power Shift + Power
VOL + Vol + Tv	SHIFT + + VOL Shift + Vol +
VOL − Vol - Tv	SHIFT + VOL − Shift + Vol -
1 Tv	SHIFT + TV 1 Shift + 1
2 Tv	SHIFT + DVD 2 Shift + 2
3 Tv	SHIFT + CD-STB 3 Shift + 3
4 Tv	SHIFT + VIDEO 4 Shift + 4
5 Tv	SHIFT + TAPE 5 Shift + 5

Originale	Sostituto
6 DVD 6 Tv	SHIFT + TUNER 6 Shift + 6
7 TAPE 7 Tv	SHIFT + AUX-HDD 7 Shift + 7
8 TUNER 8 Tv	SHIFT + USB 8 Shift + 8
9 CD 9 Tv	SHIFT + BLUETOOTH 9 Shift + 9
0 DIMMER 0 Tv	SHIFT + HDMI-SAT 0 Shift + 0
+10 Tv	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--
PREVIOUS MENU MUTING Muting/Previous Menu Tv	SHIFT + DIMMER MUTE Shift + Mute / Dimmer
ENTER Enter Tv	SHIFT + OK Shift + OK
PLAYLIST/CAT Right Tv	SHIFT + Shift + Right
PLAYLIST/CAT Left Tv	SHIFT + Shift + Left
SETUP Setup Tv	TOP MENU D.MENU D. Menu / Top
Up Tv	SHIFT + Shift + Up
Down Tv	SHIFT + Shift + Down

Originale		Sostituto	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
+10	+10/10/-/--	GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI-SAT 0	0
CLR	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home

Originale		Sostituto	
PREVIOUS MENU MUTING	Previous Menu/Muting	DIMMER MUTE	Mute / Dimmer
PLAYLIST/CAT	Left/Playlist/Ca		Left
ENTER	Enter	OK	OK
PLAYLIST/CAT	Right/Playlist/C		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-

Originale	Sostituto	Originale	Sostituto
Listening Mode >	SHIFT + PRESET+		
Audio	LANG I/II AUDIO		
Subtitle	EQ SUBTITLE		
Random	Prime Video RANDOM		
Repeat	APP REPEAT		
Display	MEDIA DISPLAY		
Play Mode VCR	FORMAT PICTURE		
DVD	SHIFT + DVD 2		
HDD	SHIFT + AUX - HDD 7		

Originale		Sostituto	
ON/STANDBY	On / Standby	Power	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
+10	+10/ 10/ - / - -	GUIDE EPG	Guide / EPG / - / - -
0	0/ 11	0	0
CLR	12	FAV MARKER	Fav / Marker / PC
CH DISC ALBUM +	Disc+	CH PAGE +	CH+ / Page+
VOL ▲	Vol +	VOL +	Vol +
CH DISC ALBUM −	Disc-	CH PAGE −	CH- / Page-
VOL ▼	Vol -	VOL −	Vol -

Originale		Sostituto	
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
►	Play	SLOW ►	Play / Slow
■	Stop	HOLD ■	Stop / Hold
◄◄	<<	TUNE- ◄◄	<< / Tune-
►►	>>	TUNE+ ►►	>> / Tune+
⏮	I <<	PRESET- ⏮	I << / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND ⏏	Eject / Surround
◄	< Listening Mode	SHIFT + PRESET- ⏮	Shift + I << / Preset-
►	Listening Mode >	SHIFT + PRESET+ ⏭	Shift + >>I / Preset+
RANDOM LEVEL-	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Originale		Sostituto	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10/10/-/--	GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI-SAT 0	0
CH DISC ALBUM +	CH+	CH PAGE +	CH+ / Page+
CH DISC ALBUM −	CH-	CH PAGE −	CH- / Page-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Originale		Sostituto	
	<<	TUNE-	<< / Tune-
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
PLAY MODE VCR	Play Mode	TOP MENU D.MENU	D.Menu / Top
L NIGHT DVD	L. Night	TIMER SLEEP	Sleep / Timer