Originale		Sostituto	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
MUTE	Mute	MUTE	Mute
PAUSE	Pause		Pause
RECALL	Recall	RETURN BACK	Back
MENU	Menu	TOP MENU MENU	Menu
SLEEP	Red / Sleep	A	Red
SLEEP	Red / Sleep	SHIFT +	Shift + Power

Originale		Sostituto	
LIST	Green / List	B	Green
LIST	Green / List	DISC NAV LIST	List
	Yellow / <<	C	Yellow
	Yellow / <<		<<
	Blue / >>	D	Blue
	Blue / >>		>>
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
9PIC	9PIC	APP MEDIA	Media
AUDIO	Audio	SOUND DUAL	Dual
TV/RADIO	TV / Radio	SEARCH TV/R	TV/R
TV/VCR	TV / VCR	TIMER AV	AV
N/P	N / P	ECO 3D	3D

Originale		Sostituto	
FAV	FAV	FAV PRE-CH	Pre Ch
TEXT	Text	REPEAT TEXT	Text
EPG	EPG	-/-- GUIDE	Guide
SUBTITLE	Subtitle	AD SUBT	Subt
INFO	Info	DISPLAY INFO	Info

Originale	Sostituto