Originale		Sostituto	
	Power		Power
TV ASPECT	Tv Aspect / AV Lin	ECO 3D	3D
TV / TEXT	Tv/ Text	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
INPUT SELECT AV	AV/ I nput Sel ec	TIMER AV	AV
-/--	- / - -	-/-- GUIDE	Gui de
VOLUME +	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -

Originale		Sostituto	
CKING/V-LOCK +	Tracki ng/ V. Lock+	+ CH	Ch +
–	Tracki ng/ V. Lock-	CH –	Ch -
	Prog. / Check Up	SHIFT + + CH	Shi f t + Ch +
PROG./CHEC	Prog. / Check Down	SHIFT + CH –	Shi f t + Ch -
	Red	A	Red
+ DATE	Gr een	B	Gr een
+ ON	Yel l ow	C	Yel l ow
+ OFF	Bl ue	D	Bl ue
+ OFF	Of f +		Up
OFF –	Of f -		Down
+ ON	On+		Ri ght
ON –	On-		Left
+ DATE	Dat e+	HOME SMART	Smart
DATE –	Dat e-	APP MEDIA	Medi a

Originale		Sostituto	
	Power		Power
DIRECT TV REC	Direct Tv Rec	SEARCH TV/R	TV/R
TV ASPECT	Tv Aspect/AV Lin	ECO 3D	3D
TV/TEXT	Tv/Text	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/-- GUIDE	Guide
INPUT SELECT AV	AV/Input Selec	TIMER AV	AV
TRACKING/V-LOCK	Tracking/V-Lock+	CH +	Ch +

Originale		Sostituto	
	Tracking/V-Lock-	CH −	Ch -
VOLUME +	Vol +	VOL +	Vol +
−	Vol -	VOL −	Vol -
LIBRARY/SEARCH	Library/Search	HOME SMART	Smart
INDEX	Index <<	<<	Index <<
INDEX	Index >>I	>>I	>>I
SV/V+	SV/V+	APP MEDIA	Media
STILL ALBUM	--/Still Albu	RETURN BACK	Back
REPLAY	Replay	AD SUBT	Subt
II/I▶	Pause/Step	II	Pause
REC	Rec	REC MODE	Rec
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Play	PLAY MODE ▶	Play

Originale		Sostituto	
	Stop		Stop
	>>		>>
	<<		<<
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Prog. / Check Up	SHIFT + CH +	Shift + Ch +
PROG./CHECK	Prog. / Check Down	SHIFT + CH −	Shift + Ch -
+ DATE	Date+	SHIFT + HOME SMART	Shift + Smart
DATE −	Date-	SHIFT + APP MEDIA	Shift + Media
+ ON	On+	B	Green
ON −	On-	A	Red
+ OFF	Off +	D	Blue
OFF −	Off -	C	Yellow
PROG./CHECK	Prog. Check	PROG SLEEP	Sleep
CANCEL	Cancel	DISC NAV LIST	List
SP/LP/EP	SP/ LP/ EP	PICTURE FORMAT	Format
TIMER	Timer	SHIFT + TIMER AV	Shift + AV

Originale		Sostituto	
I-TIMER	I - Timer	SETTINGS OPT	Options
AUDIO	Audio	SOUND DUAL	Dual
OSD/DISPLAY	OSD/ Display	DISPLAY INFO	Info
RESET	Reset	E-MANUAL D.MENU	D. Menu