Originale		Sostituto	
POWER	Power		Power
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
VPS/PDC	VPS/PDC	PC FAV MARKER	Fav / Marker / PC
	Right VPS/PDC	EQ SUBTITLE	Subtitle / EQ
AV LINK	AV Link	MEDIA DISPLAY	Display / Media
TIMER REC	Timer Rec	SIZE ZOOM	Zoom / Size
	Right Av Link	FORMAT PICTURE	Picture / Format
OSD/DISPLAY	OSD/Display	ANGLE INFO	Info / Angle
RESET	Reset	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Originale		Sostituto	
OK	OK	OK	OK
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
DIRECT TV REC	Direct Tv Rec	PROGRAM TV/RADIO	TV/Radio /
	>>	TUNE+	>> / Tune+
	<<	TUNE-	<< / Tune-
	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MENU	Menu	HOME MENU	Menu / Home
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9

Originale		Sostituto		Originale		Sostituto
0	0	HDMI - SAT 0	0			
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--			
INPUT SELECT	AV/Input Selec	RDS AV INPUT	AV / Input / RDS			
TV/TEXT	Tv/Text	GOTO TEXT	Text / Goto			
TRACKING/V-LOCK+	Tracking/V-Lock+	CH PAGE +	CH+ / Page+			
	Tracking/V-Lock-	CH PAGE -	CH- / Page-			
PAUSE/SLOW	Pause/Slow	STEP - FREEZE	Pause / Step / Freeze			
REC	Rec	REC MODE	Rec / Rec Mode			
SEARCH	Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /			
INDEX	Index <<	PRESET-	<< / Preset-			
INDEX	Index >>	PRESET+	>> / Preset+			
	Vol +	VOL +	Vol +			
	Vol -	VOL -	Vol -			

Originale		Sostituto	
POWER	Power		Power
	Prog/Check Up	SHIFT +	Shift + Up
	Prog/Check	SHIFT +	Shift + Down
DATE +	Date+	SHIFT + CH PAGE +	Shift + CH+ /
	Date-	SHIFT + CH PAGE −	Shift + CH- /
ON +	On+	TIMER SLEEP	Sleep / Timer
	On-	GOTO TEXT	Text / Goto
OFF +	Off+	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Off-	Prime Video RANDOM	Blue / Prime Video / Random
PROG/CHECK	Prog/Check	-/-- GUIDE EPG	Guide / EPG / -/--
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
VPS/PDC	VPS/PDC	PC FAV MARKER	Fav / Marker / PC
	Right VPS/PDC	EQ SUBTITLE	Subtitle / EQ
TIMER REC	Timer Rec	SIZE ZOOM	Zoom / Size
AV LINK	AV Link	MEDIA DISPLAY	Display / Media
	Right Av Link	FORMAT PICTURE	Picture / Format
OSD/DISPLAY	OSD/Display	ANGLE INFO	Info / Angle

Originale		Sostituto	
RESET	Reset	OPT-TOOLS SETUP	Setup / OPT /
DIRECT TV REC	Direct Tv Rec	PROGRAM TV/RADIO	TV/Radio /
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	OK
	Play	SLOW ▶	Play / Slow
	Stop	HOLD ■	Stop / Hold
	>>	TUNE+ ▶▶	>> / Tune+
	<<	TUNE- ◀◀	<< / Tune-
	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MENU	Menu	HOME MENU	Menu / Home
SHOW VIEW	Show View	LANG I/II AUDIO	Audio / Lang I/II
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3

Originale		Sostituto	
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX - HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	0	HDMI - SAT 0	0
	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
TRACKING/V-LOCK	Tracking/V-Look+	CH PAGE +	CH+ / Page+
	Tracking/V-Look-	CH PAGE -	CH- / Page-
INPUT SELECT	AV/Input Selec	RDS AV INPUT	AV / Input / RDS
PAUSE/SLOW	Pause/Slow	STEP - FREEZE	Pause / Step / Freeze
REC	Rec	REC MODE	Rec / Rec Mode
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
INDE	I<< Index	PRESET-	I<< / Preset-
NDEX	>>I Index	PRESET+	>>I / Preset+
	Vol +	VOL +	Vol +

Originale		Sostituto	
	Vol -	VOL -	Vol -