Originale		Sostituto	
TV	Power Tv	SHIFT +	Shift + Power
VOLUME +	Volume+ Tv	+ VOL	Vol+
	CH+ Tv	SHIFT + + CH PAGE	Shift + CH+ /
AV	AV Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
	Volume- Tv	VOL −	Vol-
	CH- Tv	SHIFT + CH PAGE −	Shift + CH- /
VCR	Power VCR		Power
OSD/DISPLAY	OSD/Display	MEDIA DISPLAY	Display / Media
RESET	Reset	RETURN BACK	Back / Return
TRACKING/V-LOCK	Tracking-V-Lock	+ CH PAGE	CH+ / Page+
REPLAY	Replay	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
AV LINK	AV Link	RDS AV INPUT	AV / Input / RDS
	Tracking-V-Lock Down	CH PAGE −	CH- / Page-
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
INDEX	I<< Index	PRESET-	I<< / Preset-
INDEX	Index >>I	PRESET+	>>I / Preset+

Originale		Sostituto	
REC	Rec	REC MODE	Rec / Rec Mode
MENU	Menu	HOME MENU	Menu / Home
	Play	SLOW	Play / Slow
	Up		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	<<	TUNE-	<< / Tune-
	Left		Left
OK	OK	OK	OK
	Right		Right
	>>	TUNE+	>> / Tune+
I-TIMER	I-Timer	LIST SMART	Smart / List
	Stop	HOLD	Stop / Hold
	Down		Down
	Pause/Step	STEP-FREEZE	Pause / Step / Freeze
PROG./CHECK	Prog/Check	PROGRAM TV/ RADIO	TV/Radio /
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
SP/LP/EP	SP/LP/EP	FORMAT PICTURE	Picture / Format

Originale	Sostituto	Originale	Sostituto
Timer	Sleep / Timer		
Prog/Check Up	Shift + Up		
Date+	1		
On+	2		
Off+	3		
Prog/Check	Shift + Down		
Date-	4		
On-	5		
Off-	6		