Mandis shop

Philips 996580000536

Originale		Sostituto	
	Power		Power
COAX	Coax	A	Red
	Play	PLAY MODE	Play
	Pause		Pause
OPTICAL	Optical	B	Green
AUX	AUX	C	Yellow
USB	USB	D	Blue
	I<		I<<
	>I		>>I
	Vol+	VOL +	Vol +
	Vol-	VOL −	Vol -
	Mute	MUTE	Mute
TREBLE +	Treble+	CH +	Ch +
TREBLE −	Treble-	CH −	Ch -
BASS +	Bass+		Up
BASS −	Bass-		Down
AUDIO SYNC −	Audio Sync -		Left

Originale		Sostituto	
AUDIO SYNC +	Audio Sync +		Right
OFF SURROUND	Surround Off	PICTURE FORMAT	Format
SURROUND ON	Surround On	ECO 3D	3D
SOUND	Sound	SOUND DUAL	Dual
DIM	DIM	APP MEDIA	Media
NIGHT	Night	HOME SMART	Smart
	Bluetooth	- / -- GUIDE	Guide
HDMI ARC	HDMI ARC	FAV PRE-CH	Pre Ch

https://tutti-i-telecomandi.it/it/Philips/1055658-66032-telecomando-di-sostituzione-per-Philips-996580000536.html