| Originale | Sostituto |
|---|---|
| Mute | Mute / Dimmer |
| Power | Power |
| (↔) | Audio / Lang I/II |
| TV | TV/ Radio / |
| _/ | Sound / Title |
| [#]→ | Picture / Format |
| [.≡] | Text / Goto |
| [≡+] | Shift + Stop / |
| [≡♦] | Shift + Zoom / |
| [≡x]◷ | Back / Return |
| [≡?][+] | Sleep / Timer |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| [≡i] | Info / Angle |
| 4 | 4 |
| 5 | 5 |

| Originale | Sostituto |
|---|---|
| 6 | 6 |
| A/B | A/B |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| Output | AV / Input / RDS |
| -/-- | Guide / EPG / -/-- |
| 0 | 0 |
| C | Exit / Cancel / Clear |
| IN 123 | IN 123 |
| 1-/TP Off | Fav / Marker / PC |
| C00 | Setup / OPT / |
| 2-/TP On | Shift + Fav / Marker / PC |
| Vol + | Vol + |
| Prog+ | CH+ / Page+ |
| Vol - | Vol - |
| Prog- | CH- / Page- |

| Originale | Sostituto |
|---|---|
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |
| Yellow | Yellow / YouTube / Repeat |
| Blue | Blue / Prime Video / Random |
| →> | Display / Media |
| -[<>] | Left |
| [<>]+ | Right |
| ♦ | Zoom / Size |
| (*) | Menu / Home |
| →← | Smart / List |
| [II··] | OK |
| [II··]+ | Up |
| [...] | Subtitle / EQ |
| Contrast+ | >>I / Preset+ |
| Brightness+ | Shift + Right |
| [II··]- | Down |
| Prog+ Down | Shift + CH+ / Page+ |

| Originale | Sostituto |
|---|---|
| Contrast- | I<< / Preset- |
| Brightness- | Shift + Left |
| Power Down | Shift + Power |
| Prog- Down | Shift + CH- / |
| << | << / Tune- |
| Play | Play / Slow |
| >> | >> / Tune+ |
| Stop | Stop / Hold |
| Pause | Pause / Step / Freeze |

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| Power Down | Power | | |
| Prog+ Down | CH+ / Page+ | | |
| Prog- Down | CH- / Page- | | |
| Stop | Stop / Hold | | |
| Pause | Pause / Step / Freeze | | |
| Rec | Rec / Rec Mode | | |
| >> | >> / Tune+ | | |
| Play | Play / Slow | | |
| << | << / Tune- | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| Power Down | Power | | |
| Prog+ Down | CH+ / Page+ | | |
| Prog- Down | CH- / Page- | | |
| Stop | Stop / Hold | | |
| Pause | Pause / Step / Freeze | | |
| Rec | Rec / Rec Mode | | |
| >> | >> / Tune+ | | |
| Play | Play / Slow | | |
| << | << / Tune- | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| Power Down | Power | | |
| Prog+ Down | CH+ / Page+ | | |
| Prog- Down | CH- / Page- | | |
| << | << / Tune- | | |
| Play | Play / Slow | | |
| >> | >> / Tune+ | | |
| Stop | Stop / Hold | | |
| Pause | Pause / Step / Freeze | | |
| Rec | Rec / Rec Mode | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |