Mandis shop

RD6901

Originale		Sostituto	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
P	P	GUIDE EPG	Guide / EPG / -/--
0	0	0	0
C	C	EXIT	Exit / Cancel / Clear
C	C	FAV MARKER	Fav / Marker / PC
TRA	I < Track	PRESET-	I << / Preset-
RACK	Track >I	PRESET+	>>I / Preset+
REVIEW	Review	INFO	Info / Angle
STOP	Stop	HOLD	Stop / Hold

Originale		Sostituto	
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
FAST	Fast	OK	OK
FTS	FTS	MENU	Menu / Home
SEARC	<< Search	TUNE-	<< / Tune-
EARCH	Search >>	TUNE+	>> / Tune+
INDE	Index-	CH PAGE	CH- / Page-
NDEX	Index+	CH PAGE	CH+ / Page+
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
	Scan	MEDIA DISPLAY	Display / Media
VOLU	Volume-	VOL	Vol -
OLUME	Volume+	VOL	Vol +
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
TIME	Time	TIMER SLEEP	Sleep / Timer
FADER	Fader	DIMMER MUTE	Mute / Dimmer
	A>B	YouTube REPEAT A-B	Yellow / YouTube / Repeat

https://tutti-i-telecomando.it/Philips/1038-280-telecomando-sostituzione-per-Philips-RD6901-RD6901.htm