Originale	Sostituto	Originale	Sostituto
Power	Power	i	Info / Angle
1	1	Up / P+	Up
2	2	Up / P+	CH+ / Page+
3	3	Z / Return	Back / Return
4	4	Left / Vol -	Left
5	5	Left / Vol -	Vol -
6	6	OK	OK
7	7	Right / Vol +	Right
8	8	Right / Vol +	Vol +
9	9	TXT / Menu	Menu / Home
? / Audio	Audio / Lang I/II	TXT / Menu	Text / Goto
0	0	Down / P-	Down
Aspect / Subtitl	Zoom / Size	Down / P-	CH- / Page-
Aspect / Subtitl	Subtitle / EQ	TV-G / Top	D. Menu / Top
PIP / Recall	Fav / Marker / PC	Red / Rec	Rec / Rec Mode
AV	AV / Input / RDS	Red / Rec	Red / Netflix / Search
Mute	Mute / Dimmer	Green / Play	Play / Slow

Originale	Sostituto	Originale	Sostituto
Green / Play	Green / APP / Repeat		
Yellow / Pause	Yellow / YouTube / Repeat		
Yellow / Pause	Pause / Step / Freeze		
Blue / Stop	Blue / Prime Video / Random		
Blue / Stop	Stop / Hold		
Scan / I<	I<< / Preset-		
PAT / >I	>>I / Preset+		
S / <<	<< / Tune-		
P / >>	>> / Tune+		

Originale		Sostituto	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	? / Langs		Audio / Lang I/II
	0		0
	[<>]/[...]		Subtitle / EQ
	PIP / Repeat		Shift + Green / APP /
	AV		AV / Input / RDS
	Mute		Mute / Dimmer
	i		Info / Angle

Originale		Sostituto	
	P+		CH+ / Page+
	Up		Up
	Vol -		Vol -
	Left		Left
	OK		OK
	Vol +		Vol +
	Right		Right
	TXT/Menu		Menu / Home
	P-		CH- / Page-
	Down		Down
	TV-G/Top Menu		D.Menu / Top
	Red/Picture/Re		Red / Netflix / Search
	Red/Picture/Re		Picture / Format
	Green/Timer/Play		Green / APP / Repeat
	Green/Timer/Play		Play / Slow
	Green/Timer/Play		Sleep / Timer
	Yellow/Pause		Yellow / YouTube / Repeat

Originale	Sostituto	Originale	Sostituto
Yellow/Pause	Pause / Step / Freeze		
Blue/Audio/Stop	Sound / Title		
Blue/Audio/Stop	Stop / Hold		
Blue/Audio/Stop	Blue / Prime Video / Random		
I◁/Scan	I<< / Preset-		
>I / PAP	>>I / Preset+		
<<◁/S	<< / Tune-		
>>▷/P	>> / Tune+		

Originale	Sostituto
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
? / Langs	Audio / Lang I/II
0	0
[<>]/[...]	Zoom / Size
[<>]/[...]	Subtitle / EQ
PIP/Repeat	SHIFT + APP REPEAT Shift + Green / APP /
AV	AV / Input / RDS
Mute	Mute / Dimmer

Originale	Sostituto
i	Info / Angle
P+	CH+ / Page+
Up	Up
Vol -	Vol -
Left	Left
OK	OK
Vol +	Vol +
Right	Right
TXT/Menu	Menu / Home
P-	CH- / Page-
Down	Down
TV-G/Top Menu	D.Menu / Top
Red/Picture/Re	Rec / Rec Mode
Red/Picture/Re	Picture / Format
Red/Picture/Re	Red / Netflix / Search
Green/Timer>/Pla	Green / APP / Repeat
Green/Timer>/Pla	Play / Slow

Originale	Sostituto	Originale	Sostituto
Green/Timer >/Pla	Sleep / Timer		
Yellow/Pause	Pause / Step / Freeze		
Yellow/Pause	Yellow / YouTube / Repeat		
Blue/Audio/Stop	Sound / Title		
Blue/Audio/Stop	Blue / Prime Video / Random		
Blue/Audio/Stop	Stop / Hold		
I</Scan	I<< / Preset-		
>I / PAP	>>I / Preset+		
<</S	<< / Tune-		
>>/P	>> / Tune+		