Mandis shop

Sanyo CXJ Y

Originale	Sostituto
POWER ON	SHIFT + Power (Shift + Power)
POWER	Power
POWER OFF	SHIFT + REPEAT TEXT (Shift + Text)
ZOOM UP	2
FOCUS UP	SHIFT + 1 (Shift + 1)
FOCUS UP 2	SHIFT + ▶ (Shift + Right)
VOL +	1
ZOOM DOWN	5
FOCUS DOWN	SHIFT + 4 (Shift + 4)
FOCUS DOWN 2	SHIFT + ◀ (Shift + Left)
VOL -	4
MUTE	9
INPUT 1	0
INPUT 2	SHIFT + 0 (Shift + 0)
MENU	MUTE (Mute)
INPUT 3	TOP MENU MENU (Menu)
INPUT NEXT	REPEAT TEXT (Text)

Originale	Sostituto
UP	▲ (Up)
LEFT	◀ (Left)
OK	OK (Ok)
RIGHT	▶ (Right)
DOWN	▼ (Down)
LENS SHIFT	7
NO SHOW	8
KEYSTONE UP	SHIFT + ▲ (Shift + Up)
FREEZE	+ CH (Ch +)
AUTO PC ADJ.	CLEAR EXIT (Exit)
KEYSTONE	SHIFT + ▼ (Shift + Down)
IMAGE	3

https://tutti-i-telecomandi.it/it/Sanyo/1617-7986-telecomando-sostituzione-per-Sanyo-CXJY-6047881.htm