Mandis shop

RB-7150

| Originale | | Sostituto | |
|---|---|---|---|
| POWER | Power | | Power |
| ▶▶I | >>I | ⏭ | >>I |
| I◀◀ | I<< | ⏮ | I<< |
| ■ | Stop | ■ | Stop |
| CD ▶/II | Play CD | PLAY MODE ▶ | Play |
| CD ▶/II | Pause CD | II | Pause |
| BAND | Band | SEARCH TV/R | TV/R |
| PRESET | Preset | HOME SMART | Smart |
| TUNER | Tuner | APP MEDIA | Media |
| TUN ^ | Tun Up | + CH | Ch + |
| TUN v | Tun Down | CH − | Ch - |
| TAPE | Tape | A | Red |
| PHONO | Phono | B | Green |
| TV | TV | C | Yellow |
| VCR | VCR | D | Blue |
| VOL ^ | Vol+ | + VOL | Vol + |
| VOL v | Vol- | VOL − | Vol - |

| Originale | | Sostituto | |
|---|---|---|---|
| MUTE RESET | Mute/Reset | MUTE | Mute |

https://tutti-i-telecomandi.it/it/Sanyo/1063470-93559-telecomando-di-sostituzione-per-Sanyo-RB-7150.html