Mandis shop

Sony RM-SC3

Originale		Sostituto	
I / ⏻	Power	⏻	Power
SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
CLOCK/TIMER SELECT	Clock Timer	TIMER AV	AV
CLOCK/TIMER SET	Clock Timer SET	ECO 3D	3D
TUNER MEMORY	Tuner Memory	1	1
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode	2	2
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode	SHIFT + PLAY MODE ▶	Shift + Play
REPEAT/ FM MODE	Repeat/FM	3	3
REPEAT/ FM MODE	Repeat/FM	REPEAT TEXT	Text
TAPE	Tape	A	Red
CD	CD	B	Green
TUNER BAND	Band/Tuner	C	Yellow
FUNCTION	Function	HOME SMART	Smart
−	I<<</-	⏮	I<<
+	>>I/+	⏭	>>I
⏪	<<	⏪	<<

Originale		Sostituto	
⏩	>>	⏩	>>
▶	Play	PLAY MODE ▶	Play
⏸	Pause	⏸	Pause
⏹	Stop	⏹	Stop
CLEAR	Clear	CLEAR EXIT	Exit
EQ	EQ	APP MEDIA	Media
ENTER	Enter	OK	Ok
DISC SKIP	Disk Skip	DISC NAV LIST	List
+ VOLUME	Vol+	+ VOL	Vol +
− VOLUME	Vol-	VOL −	Vol -
− ALBUM	Album-	CH −	Ch -
+ ALBUM	Album+	+ CH	Ch +

https://tutti-i-telecomandi.it/it/Sony/1058509-6040-telecomando-di-sostituzione-per-Sony-RM-SC-3-147851821.html