Originale		Sostituto	
I/⏻	Power	⏻	Power
SLEEP	Sleep	PROG SLEEP	Sleep
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause
■	Stop	■	Stop
BD/DVD	BD/DVD	1	1
SAT/ CATV	SAT/CATV	2	2
GAME	Game	3	3
SA-CD/ CD	SA-CD/CD	4	4
VIDEO	Video	5	5
TV	TV	6	6
FM	FM	7	7
AM	AM	8	8
USB	USB	9	9
▲	Up	▲	Up
OK	OK	OK	Ok
▼	Down	▼	Down

Originale		Sostituto	
▶	Right	▶	Right
◀	Left	◀	Left
PRESET– ⏮	I<<</Preset-	⏮	I<<
PRESET+ ⏭	>>I/Preset+	⏭	>>I
🔇	Mute	MUTE	Mute
⊿ +	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
AMP MENU	AMP Menu	TOP MENU MENU	Menu
DISPLAY	Display	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
OPTIONS	Options	SETTINGS OPT	Options
HOME	Home	HOME SMART	Smart
REPEAT	Repeat	REPEAT TEXT	Text
MOVIE	Movie	PICTURE FORMAT	Format
MUSIC	Music	SOUND DUAL	Dual
A.F.D./2CH	A.F.D./2CH	ECO 3D	3D
iPhone CTRL	iPhone Control	APP MEDIA	Media

Originale	Sostituto	Originale	Sostituto
SHUFFLE Shuf f l e	SEARCH TV/R TV/ R		