Mandis shop

Sony RM-SC30

Originale		Sostituto	
	Power		Power
	Sleep		Sleep
	Display		Info
	Select		Guide
	Set Clock/Timer		Pre Ch
	Tuner Memory		Rec
	Audio In		Red
	Play Mode/Tuning Mode		Shift + Play
	CD		Yellow
	Repeat/FM		Text
	Band/Tuner		Green
	Function		Menu
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
	Play		Play

Originale		Sostituto	
	Pause		Pause
	Stop		Stop
	Enter		Ok
	Vol+		Vol +
	Vol-		Vol -
	Folder +		Ch +
	Folder -		Ch -
	Clear		Exit
	EQ		Options

https://tutti-i-telecomandi.it/it/Sony/1062939-6157-telecomando-di-sostituzione-per-Sony-RM-SC-31-A1237274A.html