Mandis shop

RM-SD50

Originale		Sostituto	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
LOOP	Loop	HOME SMART	Smart
CD	Play CD	PLAY MODE ▶	Play
	Pause CD	II	Pause
	Stop CD	■	Stop
TUNER/BAND	Play	C	Yellow
	I<< Tuner/Band	K<	I<<
	>>I Tuner/Band	>>I	>>I
DECK A	Play Deck A	A	Red
	<< Deck A	<<	<<
	>> Deck A	>>	>>
DECK B	Play Deck B	B	Green
CHECK	Check	FAV PRE-CH	Pre Ch
EDIT	Edit	D	Blue
FUNCTION	Function	TOP MENU MENU	Menu
CLEAR	Clear	CLEAR EXIT	Exit

Originale		Sostituto	
DISC SKIP	Disc Skip	APP MEDIA	Media
	Vol+	+ VOL	Vol +
	Vol-	VOL –	Vol -
	Up	▲	Up
	Down	▼	Down
	Right	▶	Right
	Left	◀	Left
ON/OFF	On/Off	OK	Ok

https://tutti-i-telecomandi.it/it/Sony/1063680-90875-telecomando-di-sostituzione-per-Sony-RM-SD50.html