Originale		Sostituto	
SYSTEM POWER	System Power		Power
STANDBY	Standby	SHIFT +	Shift + Power
CD	CD	SHIFT + CD-STB 3	Shift + 3
MD/CD-R	MD/CD-R	SHIFT + TAPE 5	Shift + 5
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
DVD	DVD	SHIFT + DVD 2	Shift + 2
DTV/CBL	DTV/CBL	SHIFT + TV 1	Shift + 1
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
V-AUX	V-AUX	SHIFT + AUX-HDD 7	Shift + 7
MULTI CH IN	Multi CH In	SHIFT + USB 8	Shift + 8
VOLUME +	Volume +	VOL +	Vol+
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
VOLUME −	Volume -	VOL −	Vol-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STEREO 1	Stereo	TV 1	1
MUSIC 2	Music	DVD 2	2
ENTERTAIN 3	Entertain	CD-STB 3	3

Originale		Sostituto	
MOVIE 4	Movie	VIDEO 4	4
STANDARD 5	Standard	TAPE 5	5
SELECT 6	Select	TUNER 6	6
EXTD SUR. 7	Extd Sur.	AUX-HDD 7	7
DIRECT ST 8	Direct ST	USB 8	8
A SPEAKERS 9	Speakers A	BLUETOOTH 9	9
SPEAKERS B 0	Speakers B	HDMI-SAT 0	0
NIGHT +10	Night	-/-- GUIDE EPG	Guide / EPG / -/--
STRAIGHT ENT	Straight	PC FAV MARKER	Fav / Marker / PC
LEVEL TITLE	Title/Level	TITLE SOUND	Sound / Title
^	Up	▲	Up
SET MENU MENU	Set Menu	HOME MENU	Menu / Home
− <	Left/-	◀	Left
ENTER	Enter	OK	OK
> + A/B/C/D/E	Right/+	▶	Right
RETURN	Return	RETURN BACK	Back / Return
v PRESET/CH	Down	▼	Down

Originale	Sostituto	Originale	Sostituto
DISPLAY Display	MEDIA DISPLAY Display / Media		

Originale		Sostituto	
SYSTEM POWER	System Power		Power
STANDBY	Standby	SHIFT +	Shift + Power
CD	CD	SHIFT + CD-STB 3	Shift + 3
MD/CD-R	MD/CD-R	SHIFT + TAPE 5	Shift + 5
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
DVD	DVD	SHIFT + DVD 2	Shift + 2
DTV/CBL	DTV/CBL	SHIFT + TV 1	Shift + 1
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
V-AUX	V-AUX	SHIFT + AUX-HDD 7	Shift + 7
MULTI CH IN	Multi CH In	SHIFT + USB 8	Shift + 8
FREQ/TEXT	Freq/Text	NETFLIX SEARCH	Red / Netflix / Search
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
EON	EON	APP REPEAT	Green / APP / Repeat
MODE	PTY Seek Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat
START	PTY Seek Start	Prime Video RANDOM	Blue / Prime Video / Random
VOLUME +	Volume +	VOL +	Vol+
VOLUME –	Volume -	VOL –	Vol-

Originale		Sostituto	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STEREO 1	1	TV 1	1
MUSIC 2	2	DVD 2	2
ENTERTAIN 3	3	CD-STB 3	3
MOVIE 4	4	VIDEO 4	4
STANDARD 5	5	TAPE 5	5
SELECT 6	6	TUNER 6	6
EXTD SUR. 7	7	AUX-HDD 7	7
DIRECT ST. 8	8	USB 8	8
A SPEAKERS 9	9	BLUETOOTH 9	9
SPEAKERS B 0	0	HDMI-SAT 0	0
STRAIGHT ENT.	ENT	PC FAV MARKER	Fav / Marker / PC
LEVEL TITLE	Title/Level	TITLE SOUND	Sound / Title
	Up / Preset+		Up
	Up / Preset+	PRESET+	>>I / Preset+
SET MENU MENU	Menu/Set Menu	HOME MENU	Menu / Home
	Left / A/B/C/D/E-		Left

Originale		Sostituto	
ENTER	Enter	OK	OK
A/B/C/D/E	Right /		Right
RETURN	Return	RETURN BACK	Back / Return
PRESET/CH	Down / Preset-		Down
PRESET/CH	Down / Preset-	PRESET-	I<< / Preset-
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Originale	Sostituto

Originale		Sostituto		Originale		Sostituto	
POWER AV	Power AV	RDS AV INPUT	AV / Input / RDS	EON	>>I	PRESET+	>>I / Preset+
SYSTEM POWER	Power		Power	MODE	>>	TUNE+	>> / Tune+
STANDBY	Standby	SHIFT +	Shift + Power	PTY SEEK	Stop	HOLD	Stop / Hold
CD	CD	SHIFT + CD-STB 3	Shift + 3	START	<<	TUNE-	<< / Tune-
MD/CD-R	MD/CD-R	SHIFT + TAPE 5	Shift + 5	VOLUME +	Vol+	VOL +	Vol+
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6	VOLUME –	Vol-	VOL –	Vol-
DVD	DVD	SHIFT + DVD 2	Shift + 2	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DTV/CBL	DTV/CBL	SHIFT + TV 1	Shift + 1	STEREO 1	1	TV 1	1
VCR	VCR	SHIFT + VIDEO 4	Shift + 4	MUSIC 2	2	DVD 2	2
V-AUX	V-AUX	SHIFT + AUX-HDD 7	Shift + 7	ENTERTAIN 3	3	CD-STB 3	3
MULTI CH IN	Multi CH In	SHIFT + USB 8	Shift + 8	MOVIE 4	4	VIDEO 4	4
REC DISC SKIP	Disc Skip	SURROUND	Eject / Surround	STANDARD 5	5	TAPE 5	5
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer	SELECT 6	6	TUNER 6	6
	Pause	STEP-FREEZE	Pause / Step / Freeze	EXTD SUR. 7	7	AUX-HDD 7	7
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II	DIRECT ST. 8	8	USB 8	8
FREQ/TEXT	I<<	PRESET-	I<< / Preset-	A SPEAKE 9	9	BLUETOOTH 9	9
	Play	SLOW	Play / Slow	PEAKERS B 0	0	HDMI-SAT 0	0

Originale	Sostituto	Originale	Sostituto
+10	Guide / EPG / -/--		
ENT	Fav / Marker / PC		
Title	Sound / Title		
Up	Up		
Menu	Menu / Home		
Left/-	Left		
Enter	OK		
Right/+	Right		
Return	Back / Return		
Down	Down		
Display	Display / Media		

Originale		Sostituto	
SYSTEM POWER	System Power		Power
STANDBY	Standby	SHIFT +	Shift + Power
CD	CD	SHIFT + CD-STB 3	Shift + 3
MD/CD-R	MD/CD-R	SHIFT + TAPE 5	Shift + 5
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
DVD	DVD	SHIFT + DVD 2	Shift + 2
DTV/CBL	DTV/CBL	SHIFT + TV 1	Shift + 1
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
V-AUX	V-AUX	SHIFT + AUX-HDD 7	Shift + 7
MULTI CH IN	Multi CH In	SHIFT + USB 8	Shift + 8
REC DISC SKIP	Disc Skip	SURROUND	Eject / Surround
	Pause	STEP-FREEZE	Pause / Step / Freeze
FREQ/TEXT	I<<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
EON	>>I	PRESET+	>>I / Preset+
MODE	<<	TUNE-	<< / Tune-
PTY SEEK	Stop	HOLD	Stop / Hold

Originale		Sostituto	
START	>>	TUNE+	>> / Tune+
+ VOLUME	Volume +	+ VOL	Vol+
VOLUME –	Volume -	VOL –	Vol-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STEREO 1	1	TV 1	1
MUSIC 2	2	DVD 2	2
ENTERTAIN 3	3	CD-STB 3	3
MOVIE 4	4	VIDEO 4	4
STANDARD 5	5	TAPE 5	5
SELECT 6	6	TUNER 6	6
EXTD SUR. 7	7	AUX-HDD 7	7
DIRECT ST. 8	8	USB 8	8
A SPEAKE 9	9	BLUETOOTH 9	9
SPEAKERS B 0	0	HDMI-SAT 0	0
NIGHT +10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
STRAIGHT ENT.	ENT	PC FAV MARKER	Fav / Marker / PC
DISPLAY	Display	MEDIA DISPLAY	Display / Media