

EPSON
PC/PROJECTOR
EMP-62

Mandis Shop S.L.
Av. Cerdanyola Nº 75 1º Dpcho 115 08172 Sant Cugat del Vallès - Barcelona
info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
OFF	POWER				
ON	POWER				
SRC SEARCH	SOURCE SEARCH				
AUTO MODE	AUTO	COLOR MODE			
HIDE BLANK					
ASPECT RE-SYNC	RESIZE				
MENU INFO	MENU	HELP			
EXIT LAMP	ESC				
PICT FREEZE	FREEZE				
MUTE FOCUS	A/V MUTE				
ZOOM/KEYSTONE+	E-ZOOM+				
ZOOM/KEYSTONE-	E-ZOOM□-				
VOL/PAGE+	VOLUME+	PAGE UP			
VOL/PAGE-	VOLUME□-	PAGE DOWN			
∧	UP				
∨	DOWN				
<	LEFT				
>	RIGHT				
OK	OK	ENTER			
1 POINTER	POINTER	1			
2 MOUSE LEFT B.	LEFT CLICK	2			
3 MOUSE RIGHT B.	RIGHT CLICK	3			
4 VGA1	INPUT COMP 1	4			
5 VGA2	INPUT COMP 2	5			
6 COMP	INPUT COMP 1	6			
7 S-VIDEO	S-VIDEO	7			
8 VIDEO	VIDEO	8			
9 HDMI		9			
0 LAN		0			
USB					
PIP					