

OPTOMA
PC/PROJECTOR
X402

Mandis Shop S.L.
Sant Cugat del Vallès - Barcelona
info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
OFF	POWER				
ON	POWER				
SRC SEARCH	SOURCE				
AUTO MODE					
HIDE BLANK					
ASPECT RE-SYNC	ASPECT	RE-SYNC			
MENU INFO	MENU				
EXIT LAMP	BRIGHTNES				
PICT FREEZE	FREEZE				
MUTE FOCUS	MUTE				
ZOOM/KEYSTONE+	KEYSTONE UP				
ZOOM/KEYSTONE-	KEYSTONE DOWN				
VOL/PAGE+	VOLUME+	PAGE UP			
VOL/PAGE-	VOLUME-	PAGE DOWN			
∧	UP				
∨	DOWN				
<	LEFT				
>	RIGHT				
OK	ENTER				
1 POINTER		1 / ASPECT			
2 MOUSE LEFT B.	L	2 / MENU			
3 MOUSE RIGHT B.	R	3 / 3D			
4 VGA1	VGA	4 / HDMI			
5 VGA2		5 / VGA			
6 COMP		6 / VIDEO			
7 S-VIDEO		7 / USER1			
8 VIDEO	VIDEO	8 / USER2			
9 HDMI	HDMI	9 / USER3			
0 LAN	USER2	0 / BRIGHTNES			
USB	USER1				
PIP	USER3				