









































































| Originale   |         | Sostituto   |                         | Originale   |          | Sostituto   |                       |
|---|---------|---|-------------------------|---|----------|---|-----------------------|
|    | POWER   |    | Power                   |    | 9 wxyz   |    | 9                     |
|    | ←○      |    | Shift + Smart / List    |    | TV       |    | TV/Radio /            |
|    | **/0    |    | Shift + Display / Media |    | 0        |    | 0                     |
|    | *²/♀    |    | Shift + Red / Netflix / |    | ↔        |    | Shift + Back / Return |
|    | SOURCE  |    | AV / Input / RDS        |    | TV GUIDE |    | Guide / EPG / -/-     |
|    | PRESETS |    | Smart / List            |    | [≡]      |    | Text / Goto           |
|    | ≡≡≡     |    | Setup / OPT /           |    | MENU     |    | Menu / Home           |
|    | ♪/☺/▶   |    | Display / Media         |    | Q.MENU   |    | D.Menu / Top          |
|    | SLEEP   |    | Sleep / Timer           |    | UP       |    | Up                    |
|   | 1 . / @ |   | 1                       |   | LEFT     |   | Left                  |
|  | 2 abc   |  | 2                       |  | OK       |  | OK                    |
|  | 3 def   |  | 3                       |  | RIGHT    |  | Right                 |
|  | 4 ghi   |  | 4                       |  | DOWN     |  | Down                  |
|  | 5 jkl   |  | 5                       |  | BACK     |  | Back / Return         |
|  | 6 mno   |  | 6                       |  | →◻←      |  | Picture / Format      |
|  | 7 pqrs  |  | 7                       |  | EXIT     |  | Exit / Cancel / Clear |
|  | 8 tuv   |  | 8                       |  | *FAV     |  | Fav / Marker / PC     |





| Originale   |        | Sostituto   |                           |
|---|--------|---|---------------------------|
|    | VOL+   |    | Vol+                      |
|    | MUTE   |    | Mute / Dimmer             |
|    | P+     |    | CH+ / Page+               |
|    | VOL-   |    | Vol-                      |
|    | INFO   |    | Info / Angle              |
|    | P-     |    | CH- / Page-               |
|    | REC    |    | Rec / Rec Mode            |
|    | PLAY   |    | Play / Slow               |
|    | PAUSE  |    | Pause / Step / Freeze     |
|   | STOP   |   | Stop / Hold               |
|  | LANG.  |  | Audio / Lang I/II         |
|  | <<     |  | << / Tune-                |
|  | >>     |  | >> / Tune+                |
|  | [≡]... |  | Sound / Title             |
|  | RED    |  | Red / Netflix / Search    |
|  | GREEN  |  | Green / APP / Repeat      |
|  | YELLOW |  | Yellow / YouTube / Repeat |

| Originale   |      | Sostituto   |                             |
|---|------|---|-----------------------------|
|  | BLUE |  | Blue / Prime Video / Random |

