



Originale	Sostituto
 Power	 Power
 Source	 AV
 TV/DTV	 Smart
 TV/Radio	 TV/R
 Zoom	 Eject
 Mute	 Mute
 Media	 Media
 Rec	 Rec
 Sleep	 Sleep
 I/II	 Dual
 Lang	 Options
 Subtitle	 Subt
 FAV-	 Shift + Ch -
 FAV	 Pre Ch
 FAV+	 Shift + Ch +
 Red	 Red
 Green	 Green

Originale	Sostituto
 Yellow	 Yellow
 Blue	 Blue
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Info	 Info
 EPG	 Guide
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Picture	 Format
 Sound	 Shift + Dual





Originale	Sostituto
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Still	ECO 3D
Text	REPEAT TEXT
Recall	RETURN BACK
Pvr list	DISC NAV LIST
T.Shift	PLAY MODE
T.Shift	Play/T-Shift
Hold	Pause
Hold	<</Hold

Originale	Sostituto
Index	>>/Index
Size	Stop/Size
Reveal	I<</Reveal
Subpage	>>I/Subpage

