
































































	Originale	Sostituto
	Power	 Power
	Mute	 Mute
	1	 1
	2	 2
	3	 3
	4	 4
	5	 5
	6	 6
	7	 7
	8	 8
	9	 9
	0	 0
	Audio	 Dual
	Recall	 Back
	Tv-Menu	 Menu
	Source	 AV
	CH.List	 List

	Originale	Sostituto
	Exit	 Exit
	Up	 Up
	Down	 Down
	Right	 Right
	Left	 Left
	OK	 Ok
	Vol+	 Vol +
	Vol-	 Vol -
	Sound	 Shift + Dual
	PIC	 Options
	CH+	 Ch +
	CH-	 Ch -
	Sleep	 Sleep
	Aspect	 3D
	Freeze	 Shift + Media
	Tv/Radio	 TV/R
	Text	 Text





Originale	Sostituto
 EPG	 Guide
 FAV	 Pre Ch
 Info	 Info
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Reveal	 Eject
 Hold	 D. Menu
 List	 Smart
 Index	 Shift + Info
 Subpage	 Shift + Subt
 Size	 Format
 MIX	 Media
 Subtitle	 Subt
 <<	 <<
 >>	 >>

Originale	Sostituto
  <<	  <<
 >>	 >>
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Rec/Rep	 Rec

