







































































| Originale  | Sostituto   | Originale   | Sostituto  |
|--|---|---|--|
|  Power    |  Power     |  World               |  Media    |
|  Source   |  AV        |  Vol+                |  Vol +    |
|  1        |  1         |  Vol-                |  Vol -    |
|  2        |  2         |  PR+                 |  Ch +     |
|  3        |  3         |  PR-                 |  Ch -     |
|  4        |  4         |  OK                  |  Ok       |
|  5        |  5         |  Up                  |  Up       |
|  6        |  6         |  Down                |  Down     |
|  7        |  7         |  Right               |  Right    |
|  8        |  8         |  Left                |  Left     |
|  9       |  9        |  Back               |  Back    |
|  0      |  0       |  Exit              |  Exit   |
|  TV     |  TV/R    |  i                 |  Info   |
|  Mute   |  Mute    |  Guide             |  Guide  |
|  Recall |  Pre Ch  |  /Music/Photo/Movi |  Dual   |
|  Menu   |  Menu    |  [=]/Text          |  Text   |
|  Q.Menu |  D. Menu |  */o               |  Format |

| Originale  | Sostituto  | Originale   | Sostituto  |
|--|--|---|--|
|  MUTE     |  SHIFT    |  TV        |  AUX      |
|  DVD      |  SAT      |  PLAY MODE |  REC MODE |
|  1        |  1        |  II        |  ■        |
|  2        |  2        |  ⏮         |  ⏭        |
|  3        |  3        |  DISC NAV  |  SETTINGS |
|  4        |  4        |  LIST      |  OPT      |
|  5        |  5        |  DUAL     |  ECO     |
|  6       |  6       |  SEARCH  |  3D     |
|  7      |  7      |  PICTURE |  TIMER  |
|  8      |  8      |  SLEEP   |  AV     |
|  9      |  9      |  TV/R    |  |
|  0      |  0      |  FORMAT  |  |
|  TV     |  D.MENU |  REPEAT  |  |
|  MUTE   |  TEXT   |  PICTURE |  |
|  Recall |  FORMAT |   |  |
|  MENU   |  |   |  |
|  Q.MENU |  |   |  |





| Originale | Sostituto  |
|-----------|------------|
| */o..     | 3D         |
| Red       | Red        |
| Green     | Green      |
| Yellow    | Yellow     |
| Blue      | Blue       |
| Lang      | List       |
| [≡]..     | Subt       |
| [-o-]     | Shift + 3D |
| Rec       | Rec        |
| Play      | Play       |
| Pause     | Pause      |
| Stop      | Stop       |
| >>        | >>         |
| <<        | <<         |
|           |            |
|           |            |
|           |            |

| Originale | Sostituto |
|-----------|-----------|
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |

