

































































































Originale	Sostituto
 Power	 Power
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Vol+	 Vol +
 Vol-	 Vol -
 PR+	 Ch +
 PR-	 Ch -
 Exit	 Exit
 Back	 Back
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Info	 Info

Originale	Sostituto
 Menu	 Menu
 Mute	 Mute
 Source	 AV
 Swap	 Pre Ch
 0	 0
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 EPG	 Guide
 Text	 Text
 FAV	 Shift + Pre Ch





Originale		Sostituto	
	Sleep		Sleep
	Subtitle		Subt
	Lang		Dual
	Screen		Format
	Presets		Eject
	Internet		Smart
	Multimedia		Media
	Play		Play
	My Button1		List
	My Button2		D. Menu
	Rec		Rec
	Pause		Pause
	Stop		Stop
	>>		>>
	<<		<<
	>>		>>
	<<		<<

Originale		Sostituto	

