































































Originale	Sostituto
Power	 Power
Wheel Down	 +  Shift + Down
OK	 Ok
Up	 Up
Down	 Down
Wheel Up	 +  Shift + Up
Right	 Right
Left	 Left
Back	 Back
Home / Smart	 Smart
3D	 3D
123 / Q.Menu	 +  Shift + Ok
Vol +	 Vol +
Vol -	 Vol -
Mute	 Mute
P +	 Ch +
P -	 Ch -

Originale	Sostituto
Ratio	 Format
List	 List
Q.Menu	 +  Shift + Menu
Subtitle	 Subt
Settings	 +  Shift + Options
AD / PIP	 Dual
>>	 >>
>>>	 >>I
Play	 Play
<<<	 <<<
<<	 I<<<
Rec	 Rec
Pause	 Pause
Stop / Live TV	 Stop
AV Mode	 +  Shift + AV
Text	 Text
FAV	 +  Shift + Pre Ch





Originale	Sostituto	Originale	Sostituto
Exit	 Exit	T.Opt	 Options
TV / PC	 +  Shift + Smart	Q.View	 D. Menu
Input	 AV	Energy Saving	 +  Shift + 3D
TV / Radio	 TV/R	9	 9
Blue	 Blue	8	 8
Yellow	 Yellow	7	 7
Green	 Green	6	 6
Red	 Red	5	 5
0	 0	4	 4
AD	 +  Shift + Subt	3	 3
Search	 +  Shift + TV/R	2	 2
Live Menu	 Menu	1	 1
Recent	 Pre Ch	My APPS	 Media
Live Zoom	 Eject		
App	 +  Shift + Media		
Guide	 Guide		
Info	 Info		

Originale	Sostituto	Originale	Sostituto
Exit	 Exit	T.Opt	 Options
TV / PC	 +  Shift + Smart	Q.View	 D. Menu
Input	 AV	Energy Saving	 +  Shift + 3D
TV / Radio	 TV/R	9	 9
Blue	 Blue	8	 8
Yellow	 Yellow	7	 7
Green	 Green	6	 6
Red	 Red	5	 5
0	 0	4	 4
AD	 +  Shift + Subt	3	 3
Search	 +  Shift + TV/R	2	 2
Live Menu	 Menu	1	 1
Recent	 Pre Ch	My APPS	 Media
Live Zoom	 Eject		
App	 +  Shift + Media		
Guide	 Guide		
Info	 Info		

