




























































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Up/CH+		Up
	Mute		Mute / Dimmer		Info		Info / Angle
	Play		Play / Slow		Left/Vol-		Left
	Pause		Pause / Step / Freeze		OK		OK
	Stop		Stop / Hold		Right/Vol+		Right
	Rec		Rec / Rec Mode		Exit		Exit / Cancel / Clear
	<<		<< / Tune-		Down/CH-		Down
	>>		>> / Tune+		<		Back / Return
	I<<		I<< / Preset-		Vol+		Vol+
	>>I		>>I / Preset+		List		Smart / List
	S-T		Sound / Title		Prog+		CH+ / Page+
	Audio		Audio / Lang I/II		Vol-		Vol-
	3D		Picture / Format		Prog-		CH- / Page-
	Timer		Sleep / Timer		1		1
	TV/R		TV/Radio /		2		2
	TXT		Text / Goto		3		3
	Menu		Menu / Home		4		4





Originale		Sostituto	
	5		5
	6		6
	7		7
	8		8
	9		9
	EPG		Guide / EPG / -/--
	0		0
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random

Originale		Sostituto	

