



Originale	Sostituto
Power	Power
Mut e	Mut e / Di mmer
Vol +	Vol +
Vol -	Vol -
CH+	CH+ / Page+
CH-	CH- / Page-
Back	Back / Ret urn
Smart	Smart / Li st
Up	Up
Down	Down
Lef t	Lef t
Ri ght	Ri ght
OK	OK
3D	3

Originale	Sostituto





Originale	Sostituto	Originale	Sostituto
Power		Power	Power
OK		OK	OK
Up		Up	Up
Down		Down	Down
Right		Right	Right
Left		Left	Left
Back		Back / Return	Back / Return
Vol +		Vol +	Vol +
Vol -		Vol -	Vol -
Home / Smart		Menu / Home	Menu / Home
3D	+	Shift + 3	Shift + 3
Mute		Mute / Dimmer	Mute / Dimmer
P +		CH+ / Page+	CH+ / Page+
P -		CH- / Page-	CH- / Page-
Ratio		Picture / Format	Picture / Format
List		Smart / List	Smart / List
Q.Menu		D. Menu / Top	D. Menu / Top














Menu

Originale	Sostituto	Originale	Sostituto
Subtitle		Subtitle / EQ	Subtitle / EQ
Settings		Set up / OPT /	Set up / OPT /
>>>		>>> / Preset +	>>> / Preset +
>>		>> / Tune+	>> / Tune+
Play		Play / Slow	Play / Slow
AD / PIP		Sound / Title	Sound / Title
<<<		I <<< / Preset -	I <<< / Preset -
<<		<<< / Tune-	<<< / Tune-
Rec		Rec / Rec Mode	Rec / Rec Mode
Pause		Pause / Step / Freeze	Pause / Step / Freeze
Text		Text / Goto	Text / Goto
FAV		Fav / Marker / PC	Fav / Marker / PC
Exit		Exit / Cancel / Clear	Exit / Cancel / Clear
Input		AV / Input / RDS	AV / Input / RDS
Blue		Blue / Prime Video / Random	Blue / Prime Video / Random
Yellow		Yellow / YouTube / Repeat	Yellow / YouTube / Repeat
Stop / Live TV		Stop / Hold	Stop / Hold





Originale	Sostituto
AV Mde	 +  Shift + AV / Input / RDS
Green	 Green / APP / Repeat
Red	 Red / Netflix / Search
0	 0
AD	 Audio / Lang I / II
TV / PC	 +  Shift + Fav / Marker / PC
Sear ch	 +  Shift + Red / Netflix /
App	 +  Shift + Green / APP /
TV / Radi o	 TV / Radi o /
Gui de	 Gui de / EPG / - / - / -
I nfo	 I nfo / Angl e
Recent	 Sl eep / Ti ner
9	 9
8	 8
7	 7
Li ve Menu	 Di spl ay / Medi a
6	 6

Originale	Sostituto
5	 5
Q. Vi ew	 +  Shift + Di spl ay / Medi a
4	 4
Li ve Zoom	 Zoom / Si ze
3	 3
2	 2
1	 1
T. Opt	 +  Shift + Set up / OPT / Tool s
Energy Savi ng	 Ej ect / Surrou nd
My APPS	 +  Shift + Smart / Li st

