







































































Originale	Sostituto
 Power	 Power
 Source	 AV / Input / RDS
 TV	 Shift + 1
 [<>]	 Picture / Format
 3D	 Shift + 3
 O)I/II	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Originale	Sostituto
 Recall	 Fav / Marker / PC
 [i+]	 Info / Angle
 AD	 Sound / Title
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+
 P-	 CH- / Page-
 Text	 Text / Goto
 Quick	 Display / Media
 List	 Smart / List
 Menu	 Menu / Home
 Guide	 Guide / EPG / -/-
 [.]	 D.Menu / Top
 [>]	 Setup / OPT /
 Exit	 Exit / Cancel / Clear
 Up	 Up





	Originale	Sostituto	Originale	Sostituto
	Down	Down		Blue / Prime Video / Random
	Right	Right		>> / Tune+
	Left	Left		l<< / Preset-
	Back	Back / Return		>>l / Preset+
	OK	OK		TV/Radio /
	>>	Shift + Right		
	Play	Play / Slow		
	<<	Shift + Left		
	Stop	Stop / Hold		
	Pause/Step	Pause / Step / Freeze		
	↑↑	Shift + Up		
	↓↓	Shift + Down		
	Rec	Rec / Rec Mode		
	Red	Red / Netflix / Search		
	Green	Green / APP / Repeat		
	Yellow	Yellow / YouTube / Repeat		
	<</[≡+]	<< / Tune-		

