Mandis shop

Yamaha VR09390

Originale	Sostituto	Originale	Sostituto
Power	Power	Tuner	6
Sleep	Sleep / Timer	Dir A Tape	Menu / Home
Phono	2	Deck A/B Tape	Smart / List
I<< CD	I<< / Preset-	Dir B Tape	Info / Angle
>>I CD	>>I / Preset+	Tape	5
Play CD	Play / Slow	<< Tape	Left
CD	3	Play Tape	OK
<< CD	<< / Tune-	>> Tape	Right
>> CD	>> / Tune+	Rec Pause Tape	Up
Pause CD	Pause / Step / Freeze	Stop Tape	Down
Stop CD	Stop / Hold	Rec Mute	Mute / Dimmer
Disc Skip CD	Eject / Surround	AUX	7
Preset- Tuner	CH- / Page-	Vol -	Vol -
Preset- Tuner	Shift + I<< / Preset-	Vol +	Vol +
Preset+ Tuner	CH+ / Page+		
Preset+ Tuner	Shift + >>I / Preset+		
A/B/C/D/E Tuner	Display / Media		

https://tutti-i-telecomandi.it/it/Yamaha/13223-108-telecomando-sostituzione-per-Yamaha-VR390-VR390.htm