






























Originale	Sostituto
[i+]/[?]	Info / Angle
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
[=]	Text / Goto
0	0
Recall	Back / Return
Digital/Analog	Display / Media
A/B	Shift + Yellow / YouTube /
Format	Picture / Format

Originale	Sostituto
[> <]	Shift + Picture / Format
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
[I]	Guide / EPG / -/--
Up	Up
Source	AV / Input / RDS
Left	Left
OK	OK
Right	Right
Return	Shift + Back / Return
Down	Down
Tools	Setup / OPT /
Menu	Menu / Home
I<<	I<< / Preset-
←	Shift + << /

Tune-





Originale	Sostituto
 [i+]/[?]	 Info / Angle
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Back / Return
 A/B	 Yellow / YouTube / Repeat
 Up	 Up
 Left	 Left
 OK	 OK

Originale	Sostituto
 Right	 Right
 Return	 Shift + Back / Return
 Down	 Down
 I<<	 I<< / Preset-
 ←	 Shift + << /
 →	 Shift + >> /
 >>I	 >>I / Preset+
 <II/<I/<<	 << / Tune-
 Play	 Play / Slow
 >>I/>II>	 >> / Tune+
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Top Menu	 D.Menu / Top
 Menu BD/DVD	 Menu / Home









































































Originale	Sostituto	Originale	Sostituto
[i+]/[?]	Info / Angle	Green	Green / APP / Repeat
Power	Power	Yellow	Yellow / YouTube / Repeat
1	1	Blue	Blue / Prime Video / Random
2	2	Up	Up
3	3	Left	Left
4	4	OK	OK
5	5	Right	Right
6	6	Return	Back / Return
7	7	Down	Down
8	8	Tools	Setup / OPT /
9	9	Menu	Menu / Home
[≡]	Text / Goto	I<< / Preset-	I<< / Preset-
0	0	>>I / Preset+	>>I / Preset+
Digital/Analog	Display / Media	<< / Tune-	<< / Tune-
[+]	Shift + Stop /	Play	Play / Slow
[><]	Picture / Format	>>I/>/II>	>> / Tune+
Red	Red / Netflix / Search	Theatre	Smart / List





Originale	Sostituto	Originale	Sostituto
 [i+]/[?]	 ANGLE INFO Info / Angle	 OK	 OK OK
 Power	 Power	 Right	 Right
 1	 TV 1 1	 Return	 SHIFT + BACK Shift + Back / Return
 2	 DVD 2 2	 Down	 Down
 3	 CD - STB 3 3	 Menu	 HOME MENU Menu / Home
 4	 VIDEO 4 4	 I<<	 PRESET- I<< / Preset-
 5	 TAPE 5 5	 ←	 SHIFT + TUNE- Shift + << /
 6	 TUNER 6 6	 →	 SHIFT + TUNE+ Shift + >> /
 7	 AUX - HDD 7 7	 >>I	 PRESET+ >>I / Preset+
 8	 USB 8 8	 <II/<I/<<	 TUNE- << / Tune-
 9	 BLUETOOTH 9 9	 Play	 SLOW Play / Slow
 0	 HDMI - BAT 0 0	 >>I/>II>	 TUNE+ >> / Tune+
 Recall	 RETURN BACK Back / Return	 Pause	 STEP - FREEZE Pause / Step / Freeze
 A/B	 YouTube REPEAT A-B Yellow / YouTube / Repeat	 Stop	 HOLD Stop / Hold
 Up	 Up	 Mute	 DIMMER MUTE Mute / Dimmer
 Source	 RDS AV INPUT AV / Input / RDS	 Vol+	 + VOL Vol+
 Left	 Left	 Vol-	 - VOL Vol-



