












































| Originale | Sostituto |
|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
|  Power |  Power |
|  Rec |  Rec / Rec Mode |
|  Red |  Red / Netflix / Search |
|  I<< |  I<< / Preset- |
|  Green/[] |  Green / APP / Repeat |
|  Stop |  Stop / Hold |
|  Yellow |  Yellow / YouTube / Repeat |
|  Play/[≡] |  Play / Slow |
|  Blue/[■] |  Blue / Prime Video / Random |
|  >>I |  >>I / Preset+ |
|  AV/[?] |  AV / Input / RDS |
|  I-II/[≡≡] |  Audio / Lang I/II |
|  [<>]/[+] |  Picture / Format |
|  [-S-] |  Zoom / Size |
|  Menu |  Menu / Home |
|  [≡] |  Text / Goto |
|  Pause |  Pause / Step / Freeze |

| Originale | Sostituto |
|-------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
|  Left |  Left |
|  Up |  Up |
|  Right |  Right |
|  OK |  OK |
|  Down |  Down |
|  Vol+ |  Vol+ |
|  Mute |  Mute / Dimmer |
|  P+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  Smart ♪ |  Sound / Title |
|  P- |  CH- / Page- |
|  Smart [] |  Smart / List |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |





Originale

Sostituto

| | | | |
|------|------|---------------------|-------------------|
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| [i+] | [i+] | ANGLE INFO | Info / Angle |
| 0 | 0 | HDMI - BAT 0 | 0 |
| P/P | P<P | PC FAV MARKER | Fav / Marker / PC |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |






Originale

Sostituto

| | | | |
|--|--|--|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| Originale | Sostituto | Originale | Sostituto |
|---------------|-------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| 0 |  Eject / Surround |  [≡] |  Text / Goto |
| -0- |  Subtitle / EQ |  Left |  Left |
| Power |  Power |  Up |  Up |
| Rec |  Rec / Rec Mode |  Right |  Right |
| I<< |  I<< / Preset- |  OK |  OK |
| Red |  Red / Netflix / Search |  Down |  Down |
| Green/[[]] |  Green / APP / Repeat |  Vol+ |  Vol+ |
| Stop |  Stop / Hold |  Mute |  Mute / Dimmer |
| Play |  Play / Slow |  P+ |  CH+ / Page+ |
| Yellow / List |  Yellow / YouTube / Repeat |  Vol- |  Vol- |
| >>I |  >>I / Preset+ |  Smart J |  Sound / Title |
| AV/[?] |  AV / Input / RDS |  P- |  CH- / Page- |
| I-II/[≡≡] |  Audio / Lang I/II |  Smart [] |  Smart / List |
| [<>]/[+] |  Zoom / Size |  1 |  1 |
| PIP [■] |  Picture / Format |  2 |  2 |
| Menu |  Menu / Home |  3 |  3 |
| Pause |  Pause / Step / Freeze |  4 |  4 |




























| Originale | | Sostituto | |
|-----------|------|-----------|-------------------|
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | [i+] | | Info / Angle |
| | 0 | | 0 |
| | P<P | | Fav / Marker / PC |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | | Sostituto | |
|-----------|--|-----------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| Originale | Sostituto | Originale | Sostituto |
|-------------------------------------------------------------------------------------|------------|-------------------------------------------------------------------------------------|-----------------------|
|  | Power |  | Power |
|  | -O- |  | Subtitle / EQ |
|  | I<< |  | I<< / Preset- |
|  | >>I |  | >>I / Preset+ |
|  | AV/[?] |  | AV / Input / RDS |
|  | I-II/[≡ ≡] |  | Audio / Lang I/II |
|  | [<>]/[+] |  | Zoom / Size |
|  | Pause |  | Pause / Step / Freeze |
|  | [≡] |  | Text / Goto |
|  | Left |  | Left |
|  | Up |  | Up |
|  | Right |  | Right |
|  | OK |  | OK |
|  | Down |  | Down |
|  | Vol+ |  | Vol+ |
|  | Mute |  | Mute / Dimmer |
|  | P+ |  | CH+ / Page+ |

| Originale | Sostituto | Originale | Sostituto |
|---------------------------------------------------------------------------------------|-----------|---------------------------------------------------------------------------------------|-------------------|
|  | Vol- |  | Vol- |
|  | Smart J |  | Sound / Title |
|  | P- |  | CH- / Page- |
|  | Smart [] |  | Smart / List |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | P<P |  | Fav / Marker / PC |

